

# **USER'S MANUAL**

MANUAL NO. CE3000-UM-151



GRAPHTEC

### TO ENSURE SAFE AND CORRECT USE

- To ensure the safe and correct use of your cutting plotter, read this manual thoroughly prior to use.
- After reading this manual, keep it in a handy location for guick reference as necessary.
- Do not allow small children to touch the cutting plotter.
- The following describes important points for safe operation. Be sure to observe them strictly.

### **Conventions Used in This Manual**

To ensure the safe and accurate use of the cutting plotter as well as to prevent human injury and property damage, the safety precautions provided in this manual are ranked in the three categories described below. Be sure to gain a full understanding of the difference between each of the categories before reading the Manual.



**DANGER**: This category provides information that, if ignored, is highly likely to cause fatal or serious injury to the operator.



**WARNING**: This category provides information that, if ignored, is likely to cause fatal or serious injury to the operator.



: This category provides information that, if ignored, could cause injury to the operator or damage to the cutting plotter.

### **Description of Safety Symbols**



The  $\triangle$  symbol indicates information that requires careful attention (including warnings). The specific point requiring attention is described by an illustration or text within or next to the  $\triangle$  symbol.



The  $\bigcirc$  indicates an action that is prohibited. Such prohibited action is described by an illustration or text within or next to the  $\bigcirc$  symbol.



The ① symbol indicates an action that must be performed. Such imperative action is described by an illustration or text within or next to the ① symbol.

### **Safety Precautions**

### ⚠ WARNING

Do not touch the rollers or moving parts such as the carriage while cutting or plotting is in progress.

· Such action may result in injury.





#### Be sure to ground the earth terminal.

• If the cutting plotter is not grounded, the operator could suffer an electric shock in the event of current leakage.






Ground the cutting plotter


Keep your hands, hair, etc., away from the rollers or moving parts such as the carriage even if the cutting plotter is stopped, as it may suddenly start moving when data is received.

· Such action may result in injury.





• Such action may cause electric shock or a fire hazard due to current leakage.




• If the cutting plotter requires repairs, contact your sales representative or nearest Graphtec vendor.





• Use of a different supply voltage may result in electric shock or a fire hazard due to current leakage.





Do not use the cutting plotter in a location where it will be exposed to water, rain, or snow.


• Such locations may cause electric shock or a fire hazard due to current leakage.



Avoid water



Beware of electric shock



### Safety Precautions (Continued)

#### **⚠** WARNING

If the cutting plotter generates smoke, overheats, emits a strange odor, or otherwise functions abnormally, do not continue using it. Turn off the power and unplug the power cord from the electrical socket.

- Use of the cutting plotter in such a condition may result in a fire hazard or electric shock.
- After confirming that smoke is no longer being emitted, contact your sales representative or nearest Graphtec vendor for repairs.
- Never attempt to perform repairs yourself. Repair work by inexperienced personnel is extremely dangerous.





## Do not allow dust or metal scraps to adhere to the power plug.

• A dirty power plug may result in electric shock or a fire hazard due to current leakage.








Beware of electric shock

### Do not use the power cord if it is damaged.

Be careful when handling the cutter blade.

- Use of a damaged cord may result in electric shock or a fire hazard due to current leakage.
- Replace the power cord with a new one.





- Touching the blade with your bare hand may cause injury.
- Do not touch the cutter blade while cutting is in progress.





## **Safety Precautions (Continued)**

#### **⚠** CAUTION

Do not use or store the cutting plotter in a location exposed to direct sunlight or the direct draft of an air conditioner or

• Such locations may impair the performance of the cutting plotter.



Prohibited



Do not use the cutting plotter in an excessively dusty or humid location.

• Such locations may impair the performance of the cutting plotter.





Do not place any receptacle containing water or other fluid on top of the cutting plotter.

• Fluid falling inside the cutting plotter may cause electric shock or a fire hazard due to current leakage.



Avoid water






Beware of electric shock

Do not use the cutting plotter in a location subject to excessive mechanical vibration or electrical noise.

 Use in such locations may impair the performance of the cutting plotter.





When disconnecting the power cord or interface cable, do not pull on the cord/cable.

• Such action will damage the cord/cable, resulting in a fire hazard or electric shock.





If water or foreign matter enters the cutting plotter, discontinue use. Turn off the power and unplug the power cord from the electrical socket.

- Use of the cutting plotter in such a condition may result in Unplug the power electric shock or a fire hazard due to current leakage.
- Contact your sales representative or nearest Graphtec vendor for repairs.







### **Safety Precautions (Continued)**

### ⚠ CAUTION

Do not attempt to lubricate the cutting-plotter mechanisms.


• Such action may cause it to break down.





Do not clean the cutting plotter using volatile solvents such as thinner or benzene.

• Such action may impair its performance.




Provide sufficient space around the cutting plotter so that it does not strike any objects in its vicinity during cutting or plotting. Such contact may cause misalignment in cutting or plotting.





 Such contact may cause cutting or plotting to go out of alignment.

When using indoor lighting such as fluorescent or other electrical lamps, provide a distance of at least one meter between the cutting plotter and the light source.







When using the cutter, take care not to extend the blade more than necessary.

• An overly extended blade will damage the cutting mat and adversely affect the cutting quality.





Move the pen carriage slowly when moving it manually in order to load the medium or for other reasons.

• Moving it quickly may damage the cutting plotter.





### **■ CE3000 Series**

### **WARNING:**

The United States Federal Communications Commission has specified that the following notice must be brought to the attention of users of this product.

## FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### **USE SHIELDED CABLES**

To comply with FCC Class A requirements, all external data interface cables and connectors must be properly shielded and grounded. Proper cables and connectors are available from GRAPHTEC's authorized dealers or manufacturers of computers or peripherals. GRAPHTEC is not responsible for any interference caused by using cables and connectors other than those recommended or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

## **Selecting a Power Cable**

Plug Configuration	Plug Type	Reference Standards	Power Cable
	North America 125 V 10 A	ANSI C73.11 NEMA 5-15 UL498/817/62 CSA22.2 NO.42/21/49	UL Listed  Type SJT  No.18AWG x 3  300 V, 10 A
	Europe 250 V 10 A	CEE(7)VII IEC320 CEE13	TYPE: H05VV-F 3 x 1.0 mm 2
	UK 250 V 5 A	BS1363 BS4491 BS6500	TYPE: H05VV-F 3 x 1.0 mm <sup>2</sup>
	Australia 250 V 10 A	AS3112 AS3109 AS3191	TYPE: OD3CFC 3 x 1.0 mm <sup>2</sup>
	North America 250 V 15 A	ANSI C73.20 NEMA 6-15 UL 198.6	UL Listed  Type SJT  No.18AWG x 3  300 V, 10 A
	Switzerland 250 V 6 A	SEV1011 SEV1004 SEV1012	TYPE: H05VV-F 3 x 0.75 mm <sup>2</sup>

### **PREFACE**

Thank you for choosing a Graphtec CE3000-series cutting plotter. The CE3000-40 cutting plotter uses stepping motors, and the CE3000-60/120 employ a digital servo drive system to achieve high-speed and high-precision cutting. In addition to cutting marking film and other media, it can also be used as a pen plotter. To ensure high cutting quality and optimal productivity, be sure to read this User's Manual thoroughly prior to use.

### **Notes on this Manual**

- (1) No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, without the prior written permission of Graphtec Corporation.
- (2) The product specifications and other information in this manual are subject to change without notice.
- (3) While every effort has been made to provide complete and accurate information, please contact your sales representative or nearest Graphtec vendor if you find any unclear or erroneous information or wish to make other comments or suggestions.
- (4) Notwithstanding the stipulations in the preceding paragraph, Graphtec Corporation assumes no liability for damages resulting from either the use of the information contained herein or the use of the product.

### **Registered Trademarks**

All names of companies, brands, logotypes, and products appearing in this manual are the trademarks or registered trademarks of their respective companies.

## Copyright

This User's Manual is copyrighted by Graphtec Corporation.

## **Contents**

TO E	NSU	RE SAFE AND CORRECT USE	i
	Conv	ventions Used in This Manual	i
	Desc	cription of Safety Symbols	i
■ CE	3000	Series	vi
		RNING:	
		ERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY	
		ERFERENCE STATEMENT	
		SHIELDED CABLES	
Selec	ting	a Power Cable	vii
PREF	ACE		viii
	Note	s on this Manual	viii
	Regi	stered Trademarks	viii
	Copy	yright	viii
Cont	ents		ix
1	INT	RODUCTION	
•••	1.1	Checking the Accessories	1-2
	1.2	Parts Names and Functions	
		Front View (CE3000-40/60)	
		Rear View (CE3000-40/60)	
		Front View (CE3000-120)	
		Rear View (CE3000-120)	
		Control Panel	
	1.3	Assembling the Stand	
		Stand Construction	
		Stand Assembly Instructions	
	1.4	Attaching the Basket	
		Basket Construction	
		Basket Attachment Instructions	
2	CET	TING UP THE CUTTER PLOTTER	
۷.	3E I	Connecting to Your Computer	2-2
	2.2	Turning on the Power	
	2.3	Loading the Medium	
		Loading a Roll Medium	
		Loading Sheet Media	
		Aligning the Push Rollers	
	2.4	Adjusting and Mounting the Cutter Pen	
		Types and Features of Cutter Blades	
		Cutter-Pen Construction	
		Replacing the Cutter Blade	
		Adjusting the Blade Length	
		Mounting the Cutter Pen	

ა.	3.1	Setting the Format of Data to be Received	2.2
	3.1	Setting the Command Mode	
		Setting the STEP SIZE	
		Setting the ORIGIN POINT	
	3.2	Setting the Interface Conditions	
	3.3	Setting the Cutter-Pen Conditions	
	3.3	Selecting Cutter-Pen-Condition Setting Areas	
		Storing Cutter-Pen-Condition Setting Areas	
		Setting TOOL (cutter blade or pen)	
		Setting OFFSET	
		Setting FORCE	
		Setting SPEED	
		Setting QUALITY	
	3.4	Displaying the Effective Cutting Area	
	3.5	Moving the Pen	
	3.6	Setting the Initial Cutting Position	
	3.7	Stop Function	
	3.8	Moving the Pen Carriage in +100 mm Steps	
	3.9	Test Cutting	
	0.5	103t Outling	0 12
1	ELIN	CTION SETTINGS AND OPERATIONS	
٠.	4.1	PAUSE Menu List	4-2
	4.2	Setting the FEED function	
	4.3	Setting AUTO PRE-FEED	
	4.4	Setting TANGENTIAL Mode	
	4.5	Auto-Registration-Mark-Reading Settings	
		Setting the Registration-Mark Mode	
	4.6	Clearing the Buffer Memory	
	4.7	Aligning the Coordinate Axes	
	4.8	Distance Adjustment	
	4.9	Setting the PAGE LENGTH	
	4.10	Setting the Cutting/Plotting Area	
	4.11	Expanding the Cutting/Plotting Area	
	4.12	Rotating the Coordinate Axes	
	4.13	Cutting/Plotting Using the Buffer Memory	
	4.14	Sorting Settings	
	4.15	Interface Settings	
	4.16	Setting the Format of Data to be Received	
		Setting the Command Mode	
		Setting the STEP SIZE	4-32
		Setting the ORIGIN POINT	4-33
	4.17	Blade Wear Detection	
		Checking the Wear Rate	
		Setting Wear-Rate Groups	
		Setting Wear-Rate Factors	
		Clearing the Total Distance (Wear Rate)	
	4.18	Raising and Lowering the Pen	
		-	


	4.19	TEST Mode	4-39
		Condition-List Printing	4-39
		Self-Test-Pattern Printing	4-40
		Dump Mode	4-40
		Cutting Demo	4-41
	4.20	Setting the PEN UP SPEED	4-43
	4.21	Setting the OFFSET FORCE	4-44
	4.22	Setting the OFFSET ANGLE	4-45
	4.23	Setting the STEP PASS	4-46
	4.24	Setting the Initial Down Force	
	4.25	Setting the LENGTH UNIT	4-48
5.	Setti	ng and Using the Special Functions	
	5.1	Description of Special Functions A	5-2
		Enabling/Disabling the ":" and ";" Commands	
		(when the COMMAND setting is GP-GL)	5-2
		Moving the Pen While Raised or Lowered in Response to the "W" Command	
		(when the COMMAND setting is GP-GL)	5-2
		Model ID Response (when the COMMAND setting is HP-GL)	5-2
		SETTING PRIORITY	5-2
		Blade-Tip Initial Position Setting	5-2
		Enabling/Disabling PEN UP MOVE	5-3
		Enabling/Disabling the Media Sensors	5-3
		Enabling/Disabling the Home Sensors	5-3
		Setting the PARALLEL I/F Mode	5-3
		Circle-Command Resolution Setting (when the COMMAND setting is HP-GL) $\dots$	5-3
		Enabling/Disabling Blade Wear Detection	5-3
	5.2	Setting Special Functions A	5-4
	5.3	Description of Special Functions B	5-4
		Display Language Setting (MENU LANGUAGE SELECTION)	5-4
	5.4	Setting Special Functions B	5-5
6.	TRO	JBLESHOOTING	
	6.1	The Cutting Plotter Does Not Operate When Turned On	6-2
	6.2	The Cutting Plotter Does Not Operate Correctly	6-2
	6.3	The Cutting Results Are Unsatisfactory	6-3
	6.4	An Error Message Was Displayed	6-4
	ENDIX		
Apper		Main Specifications	
Apper		Options and Supplies	
Apper		External Dimensions	
Appendix D		Menu Tree	A-6

## **INDEX**

1.1	Checking the Accessories	1-2
1.2	Parts Names and Functions	1-3
1.3	Assembling the Stand	
	(CE3000-120: Standard / CE3000-60: Optional)	1-7
1.4	Attaching the Basket (CE3000-60/120: Optional)	1-10


## 1.1 Checking the Accessories

Check to confirm that all of the standard accessories listed below are present. If any item is missing, please contact your sales representative or nearest Graphtec vendor promptly.



### 1.2 Parts Names and Functions

### **■** Front View (CE3000-40/60)



Cutting mat: Cutting or plotting is performed on this mat.Grit roller: Feeds the medium backward or forwardPush rollers: Pushes the medium against the grit rollersPen carriage: Moves the cutter pen to the left and rightPen holder: Holds the cutter pen and moves it up and down


Media set lever : Raises or lowers the push rollers during loading of a medium

Control panel : Used to operate the cutting plotter and set functions

Parallel (Centronics) interface connector : Used to connect a Centronics-compatible parallel interface cable USB interface connector : Used to connect a USB cable

Serial (RS-232C) interface connector : Used to connect an RS-232C serial interface cable

### ■ Rear View (CE3000-40/60)




Roll-medium trays : Holds a roll medium

Roll-medium-tray guide rail : Used to mount the roll-medium trays

AC power inlet : Connects the power cord to the cutting plotter

Power switch : Turns the power supply to the cutting plotter on or off

### **■** Front View (CE3000-120)



**Cutting mat** ; Cutting or plotting is performed on this mat. Grit roller ; Feeds the medium backward or forward ; Pushes the medium against the grit rollers **Push rollers** Pen carriage ; Moves the cutter pen to the left and right Pen holder ; Holds the cutter pen and moves it up and down

; Raises or lowers the push rollers during loading of a medium Media set lever


; Used to operate the cutting plotter and set functions **Control panel** 

Parallel (Centronics) interface connector ; Used to connect a Centronics-compatible parallel interface cable

; Used to connect a USB cable **USB** interface connector

Serial (RS-232C) interface connector ; Used to connect an RS-232C serial interface cable

### ■ Rear View (CE3000-120)




AC power inlet Power switch Stand Stock rollers Stoppers

: Connects the power cord to the cutting plotter : Turns the power supply to the cutting plotter on or off : Supports the cutting-plotter unit

: Holds the roll media

: Used to determine the position of the roll media loaded

#### **■** Control Panel



### **Indicator Lamp**

STATUS:

Illuminates while the power to the cutting plotter is turned on, and goes out when the cutting plotter is in PAUSE status. This lamp flashes when data is being received from an interface, regardless of whether or not the cutting plotter is in PAUSE status.

### **Panel Keys**

TEST: Press this function key to conduct a cutting test and check the cutting condi-

PREV.: Press this function key to view the previous display on the LCD when in PAUSE status

Press this function key to view the next display on the LCD when in PAUSE status.

**COND.:** Press this function key to view the cutter-pen condition settings.

pause: Press this function key once in READY status to switch to PAUSE status in order to change the various settings. Press it again to cancel the PAUSE status. Pressing this key while cutting or plotting is in progress stops the cutting or plotting.

**ENTER:** Pressing this function key registers the cutting or plotting conditions set.

O O POSITION:


These keys are used to move the cursor or change the settings on the LCD display on the function setting screens. Press these keys when in PAUSE status to move the pen carriage or the medium.

ORIGIN: Press this function key to set the origin point. The pen position is set as the origin point when this key is pressed.

### 1.3 Assembling the Stand (CE3000-120: Standard / CE3000-60: Optional)

### **■** Stand Construction


The stand is made up of the following parts.




### **■** Stand Assembly Instructions


## Step 1


Fasten the stand feet (L/R) to the stand side bars (L/R) with the hexagonal socket bolts (M5), using the Allen wrench.






Fasten the stand tops (L/R) to the stand side bars (L/R) with the hexagonal socket bolts (M5), using the Allen wrench.






## Step 3

Loosely fasten the stand side bars (L/R) to the center bar with the hexagonal socket bolts (CE3000-60: M5, CE3000/20: M6), using the Allen wrench.



Mount the CE3000 cutting plotter on the stand by inserting the positioning pins on the stand into the positioning holes on the underside of the cutting plotter. Fasten using the four coin screws or hexagonal socket bolts (M6).



CHECKPOINT //

With the CE3000-120, make sure the casters with stoppers are at the front.


## Step 5

Tighten the hexagonal socket bolts loosely fastened in step 3.

### 1.4 Attaching the Basket (CE3000-60/120: Optional)

### **■** Basket Construction

The basket is made up of the following parts.



### **■** Basket Attachment Instructions

CHECKPOINT //


At least two people are required for assembly of the basket.

## Step 1


Detach the four coin screws or hexagonal socket bolts (M6), and separate the cutting plotter from the stand (see "1.3 Assembling the Stand").

## Step 2

Attach the sheet support pipe to the stand tops, and fasten using the hexagonal socket bolts.




Mount the CE3000 cutting plotter on the stand by inserting the positioning pins on the stand into the positioning holes on the underside of the cutting plotter. Fasten using the four coin screws or hexagonal socket bolts (M6).



CHECKPOINT

With the CE3000-120, make sure the casters with stoppers are at the front.

Pull out the sheet support pipe and attach the sheet. Divide the sheet over the center bar, and then fasten the sheet to the sheet support pipe using the press-studs.



2.1	Connecting to Your Computer	2-2
2.2	Turning on the Power	2-3
2.3	Loading the Medium	2-4
2.4	Adjusting and Mounting the Cutter Pen	2-11


### 2.1 Connecting to Your Computer

The cutting plotter can be connected to a computer via the parallel (Centronics-compatible) port, serial (RS-232C) port, or USB port. Select which port to use according to the requirements of your application software and/or which of your computer's interface ports are available for use.

Use a Centronics-compatible parallel cable, serial cable, or USB cable in accordance with the connection method chosen. Obtain a Graphtec approved interface cable that is compatible with the interface ports (the interface cables are available separately).


## Step 1

Check to confirm that the Power switch is turned off (the "O" side is down).



## Step 2

Connect the cable between the cutting plotter and the computer. Make sure the connectors at the cutting plotter and computer ends are correctly oriented.




## 2.2 Turning on the Power

Connect the cutting plotter to the AC electrical socket using the power cord provided, and turn on the power.


## Step 1

Check to confirm that the Power switch is turned off (the "O" side is down).




## Step 2

Connect the cutting-plotter AC power inlet to a correctly rated electrical socket using the power cord provided.



## Step 3

Turn on the cutting plotter by pressing the "I" side of the Power switch. The STATUS lamp on the control panel will light up.



If no medium has been loaded, the message below appears on the display, prompting the loading of a medium.

LOAD MEDIA!!

If a medium has already been loaded, the current media setting is displayed as shown below.

ROLL2 PRESS ENTR

Select the media mode to suit the medium used. For instructions on loading media and selecting the media mode, see "2.3 Loading the Medium."

### 2.3 Loading the Medium

Load the medium, aligning it with the right-hand grit roller when viewed from the front so that it registers with the media sensor. Then, adjust the push-roller position to match the width of the medium. The cutting plotter can use media in roll or sheet form. Load the desired medium type by following the appropriate instructions.

### ■ Loading a Roll Medium

Load the roll medium onto the roll-medium trays or stand stock rollers.


CHECKPOINT //

The roll-medium trays are provided as standard equipment with the CE3000-40/60, but cannot be used with the CE3000-120. The stand is provided as standard equipment with the CE3000-120 and is available as an option with the CE3000-60, but cannot be used with the CE3000-40.

### Loading the Roll Medium on the Roll-Medium Trays (CE3000-40/60)

## Step 1


Place the roll-medium trays flush against the roll-medium-tray guide rail, and place the roll medium on top of them. Make sure the roll-medium trays are set on the correct side with the bearings facing outward.




### Placing on the Stand (CE3000-120: Standard / CE3000-60: Optional)

## Step 1


Fit the stoppers to one of the stock rollers (loosen the screws on the stoppers first).






## Step 2

Position the stock roller with the stoppers towards the front, and place the other stock roller toward the rear to suit the roll-medium size.



## Step 3


Place the roll medium on the stock rollers, and clamp it between the stoppers. Once the position is fixed, tighten the screws on the stoppers.



### **Loading the Roll Medium**


### Step 1

Lower the media set lever to raise the push rollers.




## Step 2

Place the roll medium on the roll-medium trays or stand stock rollers, and then pass the leading edge of the medium from the back of the cutting plotter so it emerges from the front, while making sure to remove any slack in the medium conveyance path.



## Step 3

Pull the leading edge out of the front of the cutting plotter so that it completely covers the media sensor. If the leading edge has been pulled out too far, turn the roll to adjust the length of the medium that is protruding.




CHECKPOINT //

Load the medium so that it passes over the media sensor.

## Step 4

Adjust the position of the left- and right-hand push rollers to suit the width of the roll medium.

After ensuring that there is no slack in the medium's conveyance path, raise the media set lever to lower the push rollers and provide slack in the medium for a length corresponding to the length of the medium to be used.



## Step 6

Raising the media set lever displays a menu for selection of the media mode. Select the media mode.

ROLL2 PRESS ENTR

### CHECKPOINT//

If the "**REALIGN ROLLERS**" message is displayed when the medium is loaded and the media set lever is raised, either the right-hand push roller is not positioned over the right-hand wide grit roller or the left-hand or center (CE3000-120) push roller is not positioned over the grit roller. Check to confirm that they are positioned correctly.

## Step 7

Pressing the and keys displays "ROLL1 PRESS ENTR", "ROLL2 PRESS ENTR", and "SHEET PRESS ENTR". Select "ROLL2 PRESS ENTR" or "ROLL1 PRESS ENTR" and then press the (ENTER) key to confirm. When "ROLL2 PRESS ENTR" is selected, only the medium width is detected. Select this mode to begin cutting at a point beyond the leading edge. When "ROLL1 PRESS ENTR" is selected, the leading edge and width of the medium are detected. Select this mode to begin cutting from the leading edge.


### Step 8

After the medium size has been detected, the pen carriage returns to the origin point and the cutting plotter awaits cutting data. If the INTERFACE conditions or COMMAND mode have not yet been set, they should be set. If they have already been set, adjust the cutter pen. Once the cutter pen has been adjusted, the cutting plotter is ready to perform cutting, so cutting data can be sent from the application software on the computer.

### **■** Loading Sheet Media


## Step 1

Lower the media set lever to raise the push rollers.



## Step 2

With the CE3000-40/60, position the edges of the medium flush against the guide lines engraved on the front guide. With the CE3000-120, load the medium, aligning the edges with the upper and lower scales on the front guide.



## Step 3

Adjust the position of the left- and right-hand push rollers to suit the medium width.

## Step 4

Raising the media set lever displays a menu for selecting the media mode. Select the media mode.

SHEET PRESS ENTR

### CHECKPOINT

If the "REALIGN ROLLERS" message is displayed when the medium is loaded and the media set lever is raised, either the right-hand push roller is not positioned over the right-hand wide grit roller, or the left-hand or center (CE3000-120) push rollers are not positioned over the grit roller. Check to confirm that they are positioned correctly.


Pressing the and keys displays "ROLL1 PRESS ENTR", "ROLL2 PRESS ENTR", and "SHEET PRESS ENTR". Select "SHEET PRESS ENTR" and then press the (ENTER) key to confirm the selection. When "SHEET PRESS ENTR" is selected, the front and rear edges are detected.

## Step 6

After the medium size has been detected, the pen carriage returns to the origin point and the cutting plotter awaits cutting data. If the INTERFACE conditions or COMMAND mode have not yet been set, they should be set. If they have already been set, adjust the cutter pen. Once the cutter pen has been adjusted, the cutting plotter is ready to perform cutting, so cutting data can be sent from the application software on the computer.


### ■ Aligning the Push Rollers

Adjust the position of the left- and right-hand push rollers to suit the medium width. Position the push rollers at either edge of the medium so that they are above the grit rollers. Adjust the push rollers so that they are positioned above both the medium and the grit rollers. Positioning the push rollers within the push-roller alignment marks ensures that they are above the grit rollers.



**CAUTION** To move the push rollers, the media set lever must be in the lowered position.

The push roller on the right-hand edge when viewed from the front must always be moved over the right-hand wide grit roller.




CAUTION To move the push rollers, the media set lever must be in the lowered position.


### CHECKPOINT

If the "REALIGN ROLLERS" message is displayed when the medium is loaded and the media set lever is raised, either the right-hand push roller is not positioned over the right-hand wide grit roller, or the left-hand push roller is not positioned over the grit roller. Check to confirm that they are positioned correctly.

### For the CE3000-40/60

Position the push rollers over the grit rollers to grip each edge of the medium.








- The push roller (1) must be positioned over the right-hand wide grit roller.
- The medium must always be positioned over the media sensor.

### For the CE3000-120

Position push rollers (1) and (3) over the grit rollers to grip each edge of the medium, and position push roller (2) over the grit roller nearest the center of the medium. The medium is gripped by the three push rollers (1), (2), and (3).







- ♠ CAUTION Push roller (1) must be positioned over the right-hand wide grit roller.
  - The medium must always be positioned over the media sensor.

### For Minimum-Size Media

Position all of the rollers over the right-hand wide grit roller. Position the medium with the left-hand edge aligned with the left-hand edge of the grit roller, and position the push rollers over both edges. The minimum width of the medium that can be set is 50 mm for the CE3000-40/60 and 85 mm for the CE3000-120.







- CAUTION The medium must be at least 125 mm in length.
  - The medium must always be positioned over the media sensor.

#### **Adjusting and Mounting the Cutter Pen** 2.4

Individual cutter blades have a variety of features. Select the optimal cutter blade to suit the medium to be



To avoid cutting your fingers, always handle the cutter blade with caution.




#### ■ Types and Features of Cutter Blades

Part No. and profile	Blade diameter and offset	Compatible plunger	Use and features
CB 09UA	ø0.9 mm 0.45	PHP32-CB09N	The standard blade for cutting color adhesive-backed media. Suitable for cutting media up to 0.25 mm in thickness.  Max. cutting distance: Approx. 4,000 m
CB 15U	ø1.5 mm 0.75	PHP32-CB15N	Capable of cutting thicker media than possible with the CB09UA blade. Suitable for cutting media 0.25 mm to 0.5 mm in thickness.
CB 15UB	ø1.5 mm 0.15	PHP32-CB15N	Suitable for detailed cutting (e.g., letters less than 10 mm in size) of media up to 0.25 mm in thickness.


#### **■** Cutter-Pen Construction


The cutting plotter cuts using a cutter blade mounted in a cutter-pen plunger. There are two different cutter-pen plungers to suit the diameter of the cutter blade to be mounted (the 0.9-mm cutter-pen plunger is provided as standard equipment). Be sure to mount the cutter blade in the corresponding cutter-pen plunger.



### ■ Replacing the Cutter Blade


**CAUTION** To prevent cutting your fingers, always handle the cutter blade with caution.





## Step 1

Turn the blade-length adjustment knob to retract the blade into the plunger.



## Step 2

Turn the plunger cap in the counter-clockwise direction to remove it from the plunger.

## Step 3

Remove the blade from inside the plunger cap.

## Step 4

Insert the new blade into the hole provided in the plunger cap.

With the blade inserted into the plunger cap, screw on the plunger from above.


#### ■ Adjusting the Blade Length

If the blade is extended too far in relation to the thickness of the medium being cut, it will damage the cutting mat. Be sure to adjust the blade length correctly.

CAUTION To prevent cutting your fingers, always handle the cutter blade with caution.

# Step 1

Adjust the blade length by turning the blade-length adjustment knob. Turn the knob in direction "A" to extend the blade, or in direction "B" to retract the blade. When the knob is turned by one scale unit, the blade moves approximately 0.1 mm. One full turn of the knob moves the blade approximately 0.5 mm.




## Step

First align the blade tip with the tip of the cutter pen, and then extend the blade from that position to suit the thickness of the media to be cut.

# Step 3

Assuming that the medium thickness is "t," as shown in the figure below, the blade length " 1 " should be equal to or slightly greater than "t." Make sure " let " is never greater than the combined thickness of the medium and its backing sheet. If it is not possible to accurately determine the medium thickness, adjust the blade length by gradually increasing it until only traces of the blade appear on the backing sheet after a cutting test is conducted.



#### **■** Mounting the Cutter Pen


After the blade length has been adjusted, mount the cutter pen in the cutting plotter.


**A**CAUTION

To prevent cutting your fingers, always handle the cutter blade with caution.

# Step 1


Loosen the pen-holder screw and then mount the cutter pen.





# Step 2

Once the cutter pen is properly positioned, tighten the pen-holder screw.



3.1	Setting the Format of Data to be Received	3-2
3.2	Setting the Interface Conditions	3-4
3.3	Setting the Cutter-Pen Conditions	3-5
3.4	Displaying the Effective Cutting Area	3-9
3.5	Moving the Pen	3-9
3.6	Setting the Initial Cutting Position (Origin Point)	3-9
3.7	Stop Function	3-10
3.8	Moving the Pen Carriage in +100 mm Steps	3-11
3.9	Test Cutting	3-12

#### 3.1 Setting the Format of Data to be Received

Before data is sent from the computer, the format (command mode) of the data sent by the application software must be checked. The cutting plotter accepts two data formats (command modes): GP-GL (Graphtec) and HP-GL commands. Set the command mode to suit the application used.

#### ■ Setting the Command Mode

# Step 1

Check to confirm that the cutting plotter is in READY mode (displaying the current pen settings).

1 PEN 23 30 2

## Step 2

Press the (PAUSE) key to switch to PAUSE mode, and press the (NEXT) or (PREV.) keys until the menu shown below is displayed.

COMMAND

# Step 3

Press the (ENTER) key to display the menu shown below.

COMMAND HP-GL

## Step 4

Press the or key to select "GP-GL" or "HP-GL," and then press the (ENTER) key to confirm. To cancel the selection, press the (NEXT) or (PREV.) keys.

## Step 5

If "GP-GL" is selected, set the STEP SIZE. If "HP-GL" is selected, set the ORIGIN POINT. If a different command from that set previously is selected, the PAUSE mode is automatically cancelled once the STEP SIZE (GP-GL) or ORIGIN POINT (HP-GL) is set.

#### ■ Setting the STEP SIZE

If the GP-GL command mode is set, it is possible to change the minimum unit of distance that the cutter pen or pen can travel to one of four settings: 0.01 mm, 0.025 mm, 0.05 mm, or 0.1 mm. The default setting is 0.1 mm, so this setting should be changed if your application specifies a different step size.

## Step 1

Set the command setting to "GP-GL."

COMMAND GP-GL

## Step 2

Press the **(ENTER)** key to display the step-size setting.

STEP SIZE 0.100mm

## Step 3

Press the or key to select "0.100 mm," "0.050 mm," "0.025 mm," or "0.010 mm," and then press the (ENTER) key to confirm. To cancel the selection, press the (M) (NEXT) or (M) (PREV.) keys.

# Step 4

Press the (PAUSE) key to cancel the PAUSE mode.

#### ■ Setting the ORIGIN POINT

If the HP-GL command mode is set, the origin point can be set to the lower left or center. The default setting is the lower left, so this setting should be changed if your application specifies a different origin position.

## Step 1

Set the command setting to "HP-GL."

COMMAND HP-GL

# Step 2

Press the (ENTER) key to display the origin-point setting.

ORIGIN PT L.L.

# Step 3

Press the or key to select "L.L. (LOWER LEFT)" or "CENTER," and then press the (ENTER) key to confirm. To cancel the selection, press the (NEXT) or (PREV.) key.

## Step 4

Press the (PAUSE) key to cancel the pause mode.

#### 3.2 Setting the Interface Conditions

The interface conditions must be set if the RS-232C serial interface is being used. The data transfer rate (baud rate), data length, parity settings, and the handshaking mode for the cutting plotter must be set to match those of the computer operating system. This section describes the cutting-plotter interface conditions. For details on the proper settings for your application or computer operation system, refer to the manual provided with the application or operating system.

## Step 1

Check to confirm that the cutting plotter is in READY mode (displaying the current pen settings).

1 PEN 23 30 2

## Step 2

Press the (PAUSE) key to switch to PAUSE mode, and then press the (NEXT) or (PREV.) key until the menu shown below is displayed.

R S - 2 3 2 C

## Step 3

Press the (ENTER) key to display the interface settings.

▶9600 N 8 H

The current settings are displayed (from the left): transfer rate (baud rate), parity, data length, and hand-shaking mode.

The baud rate can be set to "19200," "9600," "4800," "2400," "1200," "600," or "300."

The parity can be set to "N" (None), "E" (Even parity), or "O" (Odd parity). The data length can be set to 7 or 8 bits.

The handshaking mode can be set to "H" (hard-wired handshaking) or "X" (Xon/Xoff handshaking). "E" (ENQ/ACK handshaking) can also be selected when the command mode is set to HP-GL.

All of these interface conditions must be set to match the corresponding settings in the application software and the computer operating system.

The parameter that can be changed is displayed immediately to the right of the ▶ mark. Use the ◀ or ▶ key to select the parameter to be changed, and use the ♠ or ▶ key to select the setting details. Press the ④ (ENTER) key to confirm. To cancel the selection, press the ⑥ (NEXT) or ⑥ (PREV.) key.

## Step 4

Press the (PAUSE) key to cancel the pause mode.

#### 3.3 Setting the Cutter-Pen Conditions

Before starting cutting, set the TOOL (cutter blade or pen), cutter-blade length, OFFSET, FORCE, SPEED, and QUALITY settings to ensure the optimal cutting conditions.

(1) TOOL (cutter blade or pen): Set to suit the material to be cut.

(2) Cutter-blade length: Adjust the blade length by referring to the media thickness table below.

For details on adjusting the blade length, see "2.4 Adjusting and

Mounting the Cutter Pen."

(3) OFFSET: Set to suit the cutter blade being used.

(4) FORCE: Set the FORCE by referring to the table below.
(5) SPEED: Set the SPEED by referring to the table below.
(6) QUALITY: Set the QUALITY by referring to the table below.

#### Optimal Cutting Conditions for Each Media Type

Media type	Thickness (mm)	Blade used	FORCE	SPEED	QUALITY
Film for outdoor use	0.05 to 0.08	CB09UA	10 to 14	30 or less	2
		CB15UB (for small-letter cutting)	10 to 14	20 or less	1
Film for decorative use	0.08 to 0.1	CB09UA	14 to 17	30 or less	2
Transparent or semi-transparent film	0.08 to 0.1	CB09UA	14 to 20	30 or less	2
Reflective film	0.08 to 0.1	CB09UA	14 to 20	30 or less	2
Fluorescent film	0.20 to 0.25	CB09UA, CB15U	20 to 21	10 to 20	1

#### Blade Part Nos., Displayed Blade Types, and Displayed CUTTER OFFSET Values

Blade material	Part No.	LCD display indication		Specifiable range	Initial CUTTER OFFSET	
Diage material		Blade type	Default	Specifiable range	IIIIIIIII COTTEN OFFSET	
Supersteel blades	CB09UA	09U	0	±5	18	
	CB15U	15U	0	±5	28	
	CB15UB	15B	0	±5	5	
Pens		Pen	_	_	0	

When the TOOL (cutter blade or pen) has been selected from among "**09U**," "**15U**," and "**15B**," the OFF-SET is automatically adjusted by ±5 with respect to the default cutter offset value for that blade type. Select the PEN setting for plotting using a pen. When the PEN setting is selected, no OFFSET setting is required.

#### **Reference Pen Conditions for Plotting Pens**

Pen type	FORCE	SPEED	QUALITY
Water-based fiber-tip pen	10 to 12	30	2

To preserve the pen life, set the FORCE to the lowest setting, and set the SPEED after checking to confirm that there are no faint lines or other problems during plotting.



- If the SPEED and QUALITY settings are set to high values, the cut/plotted results will have a coarser finish, but the overall cutting/plotting time will be reduced.
- If the SPEED and QUALITY settings are set to low values, the cut/plotted results will have a finer finish, but the overall cutting/plotting time will be longer.

#### ■ Selecting Cutter-Pen-Condition Setting Areas

To set the cutter-pen conditions, first select the setting area (condition number). Switching between these setting areas enables any of up to eight predefined media types to be selected easily.

#### Selection method

Press the (COND.) key in READY mode to display the cutter-pen conditions.

To select condition settings that have previously been stored, select the condition number stored on the cutter-pen-condition settings display (the number at the left of the display), using the and keys, and press the (ENTER) key. To cancel the selection, press the (NEXT), (PREV.), or (COND.) key.

#### ■ Storing Cutter-Pen-Condition Setting Areas

The cutter-pen conditions can be stored in eight setting areas numbered "1" to "8."

#### Storage method

Press the (COND.) key in READY mode to display the cutter-pen conditions.

The current settings are displayed (from the left): condition number, PEN TYPE (cutter blade), CUTTER OFFSET, FORCE, SPEED, and QUALITY.

The item to be changed is indicated by the ◀ symbol. Press the ♠ key to change the symbol to ▶, and press again to move it to the right. Press the ♠ key to move it to the left. Use the ♠ or ♠ key to select the parameter to be changed, and use the ♠ or ♠ key to select the setting details. Press the ♠ (ENTER) key to confirm. To cancel the selection, press the ♠ (NEXT), ♠ (PREV.), or ♠ (COND.) key.

#### CHECKPOINT //

When using the optional registration mark scanner, condition settings 1 and 2 are used for the pen settings when performing "Adjusting the Registration-mark Reading Sensor (2)" (refer to page 4-17). It is therefore more convenient if the cutter pen settings are assigned to 3 to 8 first.

#### ■ Setting TOOL (cutter blade or pen)

Set the type of pen (cutter blade) to be used.

# Step 1

Press the (COND.) key in READY mode to display the cutter-pen conditions.

Select the setting area (condition number) to be set, and move the ▶ symbol to the position shown below using the ⚠ or ▶ key.

2 ▶ 0 9 U + 1 2 3 3 0 2

## Step 3

Press the ♠ or ♠ key to select "09U," "15U," "15B," or "PEN." Once set, press the ♠ (ENTER) key. If other conditions are to be set, press the ♠ or ♠ key to move the ▶ symbol to the parameter to be set.

#### **■** Setting OFFSET

This setting adjusts the offset of the cutter blade to suit the blade type used. The tip of the blade mounted in the cutter-pen plunger is not positioned at the center of the pen, so correction is required. This correction is referred to as the OFFSET setting. The cutting plotter has been preset with OFFSET values for each cutter-blade type. Selecting "09U," "15U," or "15B" for the PEN TYPE setting also sets the appropriate OFFSET, allowing fine adjustment within the range of ±5. When the "PEN" setting is selected, the OFFSET cannot be set.

## Step 1

Press the (COND.) key in READY mode to display the cutter-pen conditions.

## Step 2

Select the setting area (condition number) to be set, and move the ▶ symbol to the position shown below using the ◀ or ▶ key.

2 09U>+1 23 30 2

## Step 3

Press the ♠ or ♠ key to select the value to be changed in the range of "-5" to "+5." Once set, press the ♠ (ENTER) key. If other conditions are to be set, press the ♠ or ♠ key to move the ▶ symbol to the parameter to be set.

#### **■** Setting FORCE

Sets the pressure applied by the cutter pen during cutting. Set the FORCE value based on the guidelines in the table entitled "Optimal Cutting Conditions for Each Media Type" on page 3-5.

## Step 1

Press the (COND.) key in READY mode to display the cutter-pen conditions.

## Step 2

Select the setting area (condition number) to be set, and move the ▶ symbol to the position shown below using the ◀ or ▶ key.

2 09U +1 > 23 30 2

Press the or key to select the value to be changed in the range specified below.

CE3000-40/60: "1" to "31" CE3000-120: "1" to "38"

Once set, press the (ENTER) key. If other conditions are to be set, press the or key to move the symbol to the parameter to be set.

#### **■ Setting SPEED**

Sets the speed used for cutting. Set the SPEED value based on the guidelines in the table entitled "Optimal Cutting Conditions for Each Media Type" on page 3-5.

## Step 1

Press the (COND.) key in READY mode to display the cutter-pen conditions.

# Step 2

Select the setting area (condition number) to be set, and move the ▶ symbol to the position shown below using the ◆ or ▶ key.

2 09U +1 23 > 30 2

## Step 3

Press the or key to select the value to be corrected in the range specified below.

CE3000-40: "1" to "40" CE3000-60: "1" to "60" CE3000-120: "1" to "60"; "\*"

For all cutting plotters, "1" to "10" is in increments of 1, and "10" to "40" or "60" is in increments of 5.

Once set, press the (ENTER) key. If other conditions are to be set, press the or key to move the symbol to the parameter to be set.



Selecting "\*" for the CE3000-120 sets the maximum speed. QUALITY is also set to "\*", and the acceleration of the cutter is calculated automatically.

#### **■** Setting QUALITY

Sets the acceleration used in cutting

## Step 1

Press the (COND.) key in READY mode to display the cutter-pen conditions.

## Step 2

Select the setting area (condition number) to be set, and move the ▶ symbol to the position shown below using the ♠ or ♠ key.

2 09U +1 23 30 **>**2

Press the O or key to select the value to be changed in the range specified below

CE3000-40: Fixed to "1" CE3000-60: "1", "2", "3" CE3000-120: "1", "2", "\*"

Once set, press the **②** (ENTER) key. If other conditions are to be set, press the **③** or **⑤** key to move the **▶** symbol to the parameter to be set.

CHECKPOINT

• If SPEED is set to "\*" for the CE3000-120, QUALITY is also set to "\*" and acceleration is calculated automatically.

#### 3.4 Displaying the Effective Cutting Area

Press the (ENTER) key in READY mode to display the current effective cutting area.


X 0000mm Y 000mm

#### 3.5 Moving the Pen

In READY mode, press the or key to move the pen carriage to the left or right, and the or key to feed the medium backward or forward.

#### 3.6 Setting the Initial Cutting Position (Origin Point)

This function allows the starting position for cutting or plotting to be moved to the desired position.



## Step 1

In READY mode, press the **()**, **()**, and **(POSITION)** keys to move the cutter pen to the new origin point.


# Step 2

Press the (ORIGIN) key. The following menu is displayed and the new origin is set.

ORIGIN PT SET


#### When the Origin is Moved After Rotating the Coordinate Axes

Moving the origin when the coordinate axes have been rotated gives the following results.



#### When the Coordinate Axes are Rotated After Moving the Origin Point

When the coordinate axes are rotated after the origin point is moved, the origin point is reset as shown in the figure below. The distance "a" is retained, but the distance "b" is reset.



When it is necessary to both move the origin and rotate the coordinate axes, be sure to rotate the coordinate axes first.

CHECKPOINT

After a new origin point is set, the displayed coordinate values of X= and Y= represent the respective distances from the new origin.

## 3.7 Stop Function

Cutting or plotting can be stopped by pressing the (PAUSE) key while cutting or plotting is in progress. The operation selection menu is displayed on the control-panel screen while cutting or plotting is stopped, enabling operations to be resumed or aborted as required. Raising or lowering the media set lever while the cutting or plotting is stopped does not require the medium to be selected, so the medium can be replaced or reset.

## Step 1

Press the (PAUSE) key while cutting or plotting is in progress to stop cutting or plotting and display the PAUSE menu.

FEED

Pressing the (PAUSE) key while cutting or plotting is stopped cancels the pause function and restarts cutting or plotting. To completely abort cutting or plotting, stop sending data from the computer or press the (NEXT) or (PREV.) key until the following menu is displayed.

CLEAR BUFFER

## Step 3

Press the (ENTER) key to display the buffer memory clear menu.

CLEAR <YES>

# Step 4


Press the or key to select "YES" or "NO." To abort cutting or plotting, select "YES" and press the (ENTER) key. To cancel, select "NO" and either press the (ENTER) key or press the (NEXT) or (PREV.) key.

# Step 5

Press the (PAUSE) key to reset PAUSE mode.

#### 3.8 Moving the Pen Carriage in +100 mm Steps

This function allows the pen carriage to be moved from its current position in +100 mm steps along the X-and Y-axes.



In READY mode, press the **key** while holding down the **(ENTER)** key to move the pen carriage in +100 mm steps along the X- and Y-axes.

#### Returning to the original position

In READY or PAUSE mode, press the **key** while holding down the **(ENTER)** key to return the pen carriage to the origin.

#### 3.9 Test Cutting

Test cutting can be performed after selecting the TOOL (cutter blade) and specifying the cutter-blade length, OFFSET, FORCE, SPEED, and QUALITY settings to ensure that the selected cutting conditions actually produce the desired cutting results. Check how far the blade cuts into the film and how corners are being cut; if the cutting results are not satisfactory, reset the cutting conditions and repeat the test cutting until the optimal settings are achieved. If you perform test cutting while the cutter-pen conditions are being set, the test cutting will be performed under the conditions being set.

## Step 1

Load the film for test cutting on the cutting plotter.

# Step 2


Use the **()**, **()**, and **(POSITION)** keys to move the pen carriage to the position for test cutting.

# Step 3

Select the setting area, switch to READY mode, and then press the (TEST) key.

# Step 4

Adjust the CUTTER OFFSET value to suit the type and thickness of the medium being used, and fine-adjust the finish of the corner sections. Set the FORCE so that only faint cutting lines remain on the base sheet when the blade length is properly adjusted.



## Step 5


Upon completion of fine adjustment, actual cutting data can be sent to the cutting plotter.

# FUNCTION SETTINGS AND OPERATIONS

4.1	PAUSE Menu List	4-2
4.2	Setting the FEED function	4-3
4.3	Setting AUTO PRE-FEED	4-4
4.4	Setting TANGENTIAL Mode	4-5
4.5	Auto-Registration-Mark-Reading Settings	
	(Factory Option)	4-6
4.6	Clearing the Buffer Memory	4-19
4.7	Aligning the Coordinate Axes	4-20
4.8	Distance Adjustment	4-22
4.9	Setting the PAGE LENGTH	4-24
4.10	Setting the Cutting/Plotting Area	4-25
4.11	Expanding the Cutting/Plotting Area	4-26
4.12	Rotating the Coordinate Axes	4-27
4.13	Cutting/Plotting Using the Buffer Memory	
	(COPY Function)	4-28
4.14	Sorting Settings	4-30
4.15	Interface Settings	4-31
4.16	Setting the Format of Data to be Received	4-32
4.17	Blade Wear Detection (When Blade Wear Setup is On)	4-34
4.18	Raising and Lowering the Pen	4-38
4.19	TEST Mode	4-39
4.20	Setting the PEN UP SPEED	4-43
4.21	Setting the OFFSET FORCE (Initial Cutting Force)	4-44
4.22	Setting the OFFSET ANGLE	4-45
4.23	Setting the STEP PASS	4-46
4.24	Setting the Initial Down Force	4-47
4.25	Setting the LENGTH UNIT	4-48


#### 4.1 PAUSE Menu List

Pressing the (PAUSE) key in READY mode displays the PAUSE menu, enabling the various settings to be made. Select the required menu by scrolling through the list using the (NEXT) and (PREV.) keys.




#### 4.2 Setting the FEED function

The FEED function feeds the medium forward and backward to leave faint tracks of the grit rollers on it and prevent the media from slipping during a cutting or plotting operation.



#### 4.3 Setting AUTO PRE-FEED

When the AUTO PRE-FEED function is set to "**ON**," the medium is automatically fed forward and backward by the preset length when data is received. This operation leaves traces of the grit rollers on the media and prevents it from slipping during a cutting or plotting operation. Similarly, if roll media is used, the medium is automatically pulled out by the cutting plotter.




#### 4.4 Setting TANGENTIAL Mode

This function should be used for the cutting of thick media (more than 0.3 mm in thickness) and when the cutter blade is not able to turn properly due to the cutting depth, resulting in discrepancies between the start and finish point and the inability to cut sharp corners. This function can be set on or off individually for each of the eight cutter-pen setting areas, and it should be set to suit the media used. The overcut-amount setting screen is displayed for cutter-pen setting areas for which the TANGENTIAL mode is "ON."

This setting has two modes: Mode 1 and Mode 2.

- Mode 1: Overcuts the start and finish cutting positions and acute-angle corner sections to avoid leaving uncut sections. In addition, the cutter blade is moved on the surface of the medium during cutting when it is rotated significantly, ensuring sharp cutting unaffected by the medium toughness or thickness.
- Mode 2: Overcuts the start and finish cutting positions only. In addition, the cutter is rotated on the medium surface for the start cutting position only. This uses simpler cutter control than Mode 1, and provides a shorter cutting time.



Press the (ENTER) key or move the cursor to the right-hand side using the key, and then press the key again to display the menu shown below. If the distance adjustment is set for the setting area selected, the distance adjustment will be displayed here. Either press the (ENTER) key or move the cursor to the right-hand side and press the key.

TANGENTIAL MODE 1

## Step 7

Use the and keys to select "Mode 1" or "Mode 2," and then press the (ENTER) key. The overcut setting is displayed.

STR = 0.2 END = 0.2

## Step 8

"STR" indicates the initial overcut amount, and "END" indicates the end overcut amount for the line section. Select "STR" or "END" using the or key, use the and keys to increase or decrease the values, and then press the (ENTER) key to confirm. To cancel, press the (NEXT) or (PREV.) key.


#### 4.5 Auto-Registration-Mark-Reading Settings (Factory Option)

These settings enable pre-plotted media to be cut without any offset by reading the registration marks using the cutting-plotter sensor and adjusting the axes to suit the coordinate data.



Registration-mark reading accuracy \*: Within 0.3 mm

\* Accuracy when using pens provided with the cutting plotter, high-grade media, and reading the specified pattern.



The following precautions must be observed when the registration marks are automatically read.

- · Registration-mark pattern
- · Reading range required for the detection of registration marks
- · Medium and registration-mark position
- Drawing origin point
- Medium type

The registration-mark conditions that can be read by the cutting plotter are as follows.

- Registration-mark line width: 0.3 mm to 1.0 mm (The registration-mark center lines are used as the reference points.)
- Registration-mark size: 5 mm to 20 mm (See "Setting the Registration-mark Size.")
- Registration-mark pattern: Pattern 1 or 2 (See "Setting the Registration-mark Pattern.")
- · Registration marks must be formed of single lines.
- Registration marks must be drawn in black.

The cutting plotter cannot detect registration marks on the following media types.

• Transparent media: The writing surface is also read, preventing the registration-mark lines

from being read.

Non-monochrome drawings: The registration marks cannot be read on colored media or if the registra-

tion marks are not black.

• Untidy drawings or media: The registration marks cannot be read if the medium surface is dirty or

creased, or if the registration marks are defaced.

Medium thickness: The registration marks cannot be read if the medium is more than 0.3 mm


in thickness.

#### CHECKPOINT

- The registration marks used in the application software cannot be used. The registration marks must always be created as drawing data.
- If auto mark reading is not possible, use the axis alignment function (see "Setting Axis Alignment").


#### Registration-mark pattern

The cutting plotter is capable of reading the following registration-mark patterns.



#### Reading range required for the detection of registration marks

The range required for the detection of registration marks is as shown below.




#### CHECKPOINT //

- Incorrect detection may occur if there are marks other than registration marks within the reading range. If drawings overlap the registration-mark reading range, refer to "Setting the Registration-mark detection movement distance."
- Incorrect detection may occur if the registration-mark reading range is dirty or foreign matter is adhering to the medium surface.


#### Medium and registration-mark position

Blank margins must be left between the medium edges and the registration marks to enable the marks to be read.




#### **Drawing origin point**

The drawing origin point following reading of the registration marks will be at the bottom-right registration mark, as shown below.



#### ■ Setting the Registration-Mark Mode



Use the and keys to select "OFF," "2 POINT," or "3 POINT," and then press the (ENTER) key to confirm.

## Step 6

When "2 POINT" or "3 POINT" is set, the sensors read the registration marks as soon as the medium is loaded (media set lever raised), and the following is displayed.

### MOVE TO R. MARK

To cancel the registration-mark reading and perform the normal initialization operation, press the (ORI-GIN) key. The "ROLL2 PRESS ENTR," "ROLL1 PRESS ENTR," "SHEET PRESS ENTR" selection is displayed, allowing normal initialization to be performed.

# Step 7

Move the cutter pen to the lower-right registration mark using the , , and (POSITION) keys, and press the (ENTER) key. The sensor reads between points 1 and 2 (and between 1 and 3 for 3-point alignment), and the following is displayed.

X00308.9 00308.9

#### CHECKPOINT

- If the registration-mark distance correction is set to "1 mm," "5 mm," or "10 mm," the alignment input screen is not displayed.
- The registration marks are read in accordance with the registration-mark-detection movement distance setting.


The distance between X-axis registration marks (points 1 and 2) read by the cutting plotter is displayed on the left. Enter the actual distance on the right. Move the cursor to the digit to be entered using the and keys, use the and keys to increase or decrease the values, and then press the (ENTER) key to confirm. For 3-point alignment, the distance between the Y-axis registration marks (points 1 to 3) is also displayed and should be set in the same way. To cancel, press the (NEXT) or (PREV.) keys

## Step 8

Upon completion of alignment, the cutting plotter returns to READY mode.

#### **Setting the Registration-mark detection movement distance**

This sets the distance between the registration marks and changes the initial registration-mark scanning position. Avoiding reading areas that obviously do not include registration marks increases the registration-mark reading speed and minimizes the possibility of incorrect reading due to other marks on the medium.



## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

## Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

AUTO REG. MARK

# Step 3

Press the (ENTER) key to display the Auto Reg. Mark submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK POSITION

## Step 4

Press the (ENTER) key to display the registration-mark detection movement distance X-axis setting.

 $M \cdot P \circ S \qquad X = 0 \circ 0 \circ m m$ 

## Step 5

Move the cursor to the digit to be entered using the  $\triangle$  and  $\bigcirc$  keys, use the  $\triangle$  and  $\bigcirc$  keys to increase or decrease the values, and then press the  $\bigcirc$  (ENTER) key to confirm. The Y-axis setting is then displayed and should be set in the same way.


Press the (PAUSE) key to cancel PAUSE mode.

#### CHECKPOINT //

- This setting is retained in the memory even when the power is turned off.
- If the detection movement distance is set to 0 mm, the sensor continues detecting between the registration marks without skipping until it detects the next mark.
- For 2-point alignment, the Y value is ignored.
- The medium will be ejected if the detection movement distance is set to a value greater than the medium length.

#### **Setting the Registration-mark Pattern**

The cutting plotter is capable of reading the following registration-mark patterns.



## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

# Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

AUTO REG. MARK

## Step 3

Press the (ENTER) key to display the Auto Reg. Mark submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK TYPE

## Step 4

Press the (ENTER) key to display the registration-mark pattern setting.

MARK TYPE 1

Press the or key to select "1" or "2," and then press the (ENTER) key to confirm. To cancel, press the (NEXT) or (PREV.) key.

Press the (PAUSE) key to cancel PAUSE mode.


#### CHECKPOINT

The registration-mark conditions that can be read by the cutting plotter are as follows.

- Registration-mark line width: 0.3 mm to 1.0 mm (The registration-mark center lines are used as the data.)
- Registration-mark size: 5 mm to 20 mm (See "Setting the Registration-mark Size.")
- Registration-mark pattern: Pattern 1 or 2
- Registration marks must be formed of single lines.
- Registration marks must be drawn in black.

#### Setting the Registration-mark Size

This sets the size of the registration marks to be read.



## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

# Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

AUTO REG. MARK

## Step 3

Press the (ENTER) key to display the Auto Reg. Mark submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK SIZE

## Step 4

Press the (ENTER) key to display the registration-mark size setting.

MARK SIZE 10mm

Use the and keys to set the value within the range "5 mm" to "20 mm," and then press the (ENTER) key to confirm. To cancel, press the (MEXT) or (MEXT) key.

## Step 6

Press the (PAUSE) key to cancel PAUSE mode.

#### Setting the Registration-mark Distance Adjustment

This automatically adjusts the distance between registration marks, rounding down to the nearest 1 mm, 5 mm, or 10 mm. For example, if the distance adjustment is set to 5 mm and the distance between the registration marks is read as 312 mm, the distance is rounded down to the nearest 5 mm and treated as a distance of 310 mm.

## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

# Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

AUTO REG. MARK

# Step 3

Press the (ENTER) key to display the Auto Reg. Mark submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK DIST. ADJ.

## Step 4

Press the (ENTER) key to display the registration-mark distance-adjustment setting.

MARK DIST.ADJ.OFF

## Step 5


Press the or key to select "OFF," "1 mm," "5 mm," or "10 mm," and then press the (ENTER) key to confirm. To cancel, press the (M) (NEXT) or (M) (PREV.) key.

## Step 6

Press the (PAUSE) key to cancel PAUSE mode.

#### **Setting the Registration-mark Origin Point**

If the registration-mark origin point is not set, it will be positioned as shown in the figures below. This function should be set when it is required to move the origin point from this position.



## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

## Step 2

Press the (NEXT) or (PREV.) keys until the following menu is displayed.

AUTO REG. MARK

## Step 3

Press the (ENTER) key to display the Auto Reg. Mark submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK OFFSET

# Step 4

Press the (ENTER) key to display the X-axis registration-mark origin input setting.

## Step 5


Move the cursor to the digit to be entered using the and keys, use the and keys to increase or decrease the values (or display/don't display "-" for the space to the right of "="), and then press the (ENTER) key to confirm. The Y-axis origin input setting is then displayed and should be set in the same way. To cancel, press the (NEXT) or (PREV.) key.


# Step 6

Press the (PAUSE) key to cancel PAUSE mode.

#### Adjusting the Registration-mark Reading Sensor (1)

This adjusts the position of the sensor for the reading of registration marks. The adjustment crosshairs are plotted after crosshairs already plotted have been read, and the difference between the two is input to adjust the position.





## Step 1

Load a medium with the crosshairs plotted.

# Step 2

Set the cutter pen conditions to "PEN" (refer to "3.3 Setting the Cutter-Pen Conditions"), and mount a pen in the cutting plotter.

# Step 3

Press the (PAUSE) key to switch to PAUSE mode.

# Step 4

Press the (NEXT) or (PREV.) key until the following menu is displayed.

AUTO REG. MARK

# Step 5

Press the (ENTER) key to display the Auto Reg. Mark submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK SENSOR ADJ1

## Step 6

Press the (MEXT) or (MEXT) we until the following menu is displayed.

MARK ADJ1 SCAN

## Step 7

Move the cutter pen to the position of the crosshairs already plotted on the medium using the , , and (POSITION) keys, and press the (ENTER) key. The sensor scans the crosshairs and overwrites them.

## Step 8

Measure the offset of the crosshairs in the X-axis, and enter the distance adjustment.

 $\begin{array}{|c|c|c|c|c|}\hline ADJ & X = & 0.0 \\ \hline \end{array}$ 


Move the cursor to the digit to be entered using the \( \bigcirc \) and \( \bigcirc \) keys, use the \( \bigcirc \) and \( \bigcirc \) keys to increase or decrease the values (or display/don't display "-" for the space to the right of "="), and then press the \( (\bigcirc \) (ENTER) key to confirm. If there is no offset, simply press the \( (\bigcirc \) (ENTER) key. The Y-axis distance-adjustment input is then displayed and should be set in the same way. To cancel, press the \( (\bigcirc \) (NEXT) or \( (\bigcirc \) (PREV.) key.

## Step 10

Press the (PAUSE) key to cancel PAUSE mode.

#### Adjusting the Registration-mark Reading Sensor (2)

This adjusts the position of the sensor for reading the registration marks by plotting crosshairs and then reading them. First set both cutter pen conditions 1 and 2 to the same pen. Crosshairs are first plotted using conditions 1 and read by the sensor. A second set of adjustment crosshairs is plotted using conditions 2. The difference between the two is input to adjust the position.



## Step 1

Load a medium into the cutting plotter.

## Step 2

Set both cutter pen conditions 1 and 2 to the same "Pen" (refer to "3.3 Setting the Cutter-Pen Conditions"), and load a pen in the cutting plotter.

## Step 3

Press the (PAUSE) key to switch to PAUSE mode.

# Step 4

Press the (NEXT) or (PREV.) key until the following menu is displayed.

AUTO REG. MARK

## Step 5

Press the (ENTER) key to display the Auto Reg. Mark submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK SENSOR ADJ2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

MARK ADJ2 SCAN

Step 7

Move the cutter pen to the position for plotting of the crosshairs using the , , and (POSITION) keys, and press the (ENTER) key. The crosshairs are plotted and the following is displayed.

PRESS ENTER KEY

Step 8

Press the (ENTER) key. The sensor scans the crosshairs and overwrites them.

Step 9

Measure the offset of the crosshairs on the X-axis, and enter the distance adjustment.

 $\begin{bmatrix} A D J & X = 0.0 \end{bmatrix}$ 

Step **10** 


Move the cursor to the digit to be entered using the and keys, use the and keys to increase or decrease the values (or display/don't display "-" for the space to the right of "="), and then press the (ENTER) key to confirm. If there is no offset, simply press the (ENTER) key. The Y-axis distance-adjustment input is then displayed and should be set in the same way. To cancel, press the (NEXT) or (PREV.) key.

Step 11

Press the (PAUSE) key to cancel PAUSE mode.


#### 4.6 Clearing the Buffer Memory


This function deletes the data sent to the cutting plotter. It is used to abort cutting while it is in progress.



#### 4.7 Aligning the Coordinate Axes

This function is used to compensate for any offset in the origin or angular deviation in the coordinate axes that occurs when a medium plotted in another plotter is loaded or when a previously plotted medium is reloaded. This function enables the cutting of outlines plotted using a different plotter, or drawings previously plotted to be recut. Plotting the origin and X-axis line before the coordinate axes are aligned makes it easier to adjust the axes. Plot the origin and X-axis line within the plotting area to enable settings to be specified even if the X-axis and origin are positioned at an angle. If the origin and X-axis line are plotted near the boundaries of the plotting area, the settings may lie outside the plotting area, making it impossible to align the axes.





# Step 1

Press the (PAUSE) key to switch to PAUSE mode.


# Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

AXIS ALIGNMENT

# Step 3

Press the (ENTER) key to display the axis-alignment menu.




Use the , , and (POSITION) keys to move the cutter pen to alignment point 1 (the origin on the previously plotted medium). The coordinates displayed here indicate the distance from the current origin point.

## Step 4

Press the **(ENTER)** key to set the new origin, and use this as the center of rotation for the X-axis.

Use the **()**, **()**, and **()** (POSITION) keys to move the cutter pen to alignment point 2 (any point on the X-axis for the previously plotted medium). The coordinates displayed here indicate the distance from alignment point 1.



# Step 6

Press the (ENTER) key to calculate the X-axis angle of inclination and align the axes.

## Step 7

Press the (PAUSE) key to cancel PAUSE mode.


#### **CHECKPOINT**

After the axes are aligned, the settings will be reset if any of the following are performed.

- Specification of a new origin
- · Loading of a new medium
- · Setting of the axis rotation

#### 4.8 Distance Adjustment

This function corrects any deviation in the length of cut or the plotted line segments, which occurs depending on the medium being used. The adjustment value for the deviation is specified as a percentage of the total distance. For example, a setting of 0.05% adjusts a distance of 2 m (2,000 mm) by +1 mm (2000 x 0.05% = 1 mm), to become 2,001 mm. Eight different cutter-pen condition-setting areas can be set on or off separately, allowing different settings to be made in order to suit the medium used.



## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

# Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

DISTANCE ADJUST

# Step 3

Press the (ENTER) key to display the distance adjustment menu. The numbers "1" to "8" indicate the cutter-pen condition-setting areas, and those that are set on are indicated with the symbol to the left.

Move the cursor to select the required condition-setting area using the ◆ and ▶ keys. Press the ◆ or ▼ key to display or not display the ▶ symbol, and then press the ④ (ENTER) key to confirm. To cancel, press the ⑥ (NEXT) or ⑥ (PREV.) key.

## Step 4

Press the (PAUSE) key to cancel PAUSE mode.

# Step 5

Select the condition-setting area to be set to "ON" (refer to "Selecting Cutter-Pen-Condition Setting Areas" on page 3-6).

5**∢**15U 0 20 30 1

## Step 6

Either press the (ENTER) key or use the key to move the cursor to the far right, and then press the key to display the following menu.

X = 0.00% Y = 0.00%


# Step 7

Select "X" or "Y" using the or key. Use the and keys to increase or decrease the setting within the range of "-2.00%" to "+2.00%," and then press the (ENTER) key to confirm. If the condition-setting area is set for TANGENTIAL mode, the TANGENTIAL-mode setting will be displayed. Press (ENTER) again. To cancel, press the (NEXT) or (PREV.) key.

CHECKPOINT This setting is retained in the memory even when the power is turned off.

#### 4.9 Setting the PAGE LENGTH

This function sets the length of each page when long-axis cutting or plotting is performed using a roll medium. This should be set for long-axis cutting or plotting exceeding 5 m in length. The default setting is "5000 mm."



## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

## Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

PAGE LENGTH

## Step 3

Press the (ENTER) key to display the page-length menu.

L = 05000 mm

Move the cursor to the digit to be changed using the and keys. Use the and keys to increase or decrease the setting, and then press the (ENTER) key to confirm. To cancel, press the (NEXT) or (PREV.) key.

## Step 4

Press the (PAUSE) key to cancel PAUSE mode.

#### CHECKPOINT //

- This setting is retained in the memory even when the power is turned off.
- The cutting plotter's distance precision is guaranteed for page-feed lengths of up to 5 meters, provided that the following conditions are satisfied (CE3000-60/120).
   Long-axis cutting over 5 meters is possible for lengths of up to 50 meters in the feeding direction.

Guaranteed precision conditions:

- -The cutting plotter is mounted on its stand.
- -Graphtec-specified film is used with the stipulated setting conditions.


Film: 3M plastic-backed film


Setting conditions: Cutter speed, 30 cm/s max; Quality,

- In the case of long-axis cutting, be particularly careful when loading color adhesive-backed film. If the film is loaded at even a slight angle, the film may come loose from the rollers that hold it in place.
- For long-axis cutting using roll media, pull out the length of the medium to be used, or use the pre-feed operation (see "4.2 Setting the FEED function" and "4.3 Setting AUTO PRE-FEED").

#### 4.10 Setting the Cutting/Plotting Area

This function allows the area in which cutting/plotting will be performed to be specified, thereby preventing cutting/plotting outside the specified area. This function enables more efficient use of the film through the specification of uncut portions of a film that have already been cut, to avoid the previously cut areas. Note that setting of the cutting/plotting area also repositions the origin point in accordance with the movement of the cutting area.








The following message is displayed if the lower-left and upper-right settings are not separated by a distance of at least 5 mm. If this message appears, reset the lower-left and upper-right positions.

WRONG PLOT AREA


#### 4.11 Expanding the Cutting/Plotting Area


This function allows the width of the cutting/plotting area to be extended by 9.5 mm on both sides, for a total increase of 19 mm, enabling cutting to be performed up to the area in which the pinch rollers are positioned.



#### 4.12 Rotating the Coordinate Axes


This function allows the cutting/plotting origin and coordinate axes to be rotated as shown below.






#### 4.13 Cutting/Plotting Using the Buffer Memory (COPY Function)

This function is used to make duplicate copies of cutting or plotting data that has been sent from the computer and is retained in the cutting plotter's internal memory.





# Step 1

Send the data to be copied to the cutting plotter, and cut or plot the data once.

# Step 2

Use the **()**, **()**, and **()** (POSITION) keys to move the pen to the starting position for cutting or plotting.

# Step 3

Press the (PAUSE) key to switch to PAUSE mode.

# Step 4

Press the (NEXT) or (PREV.) key until the following menu is displayed.

COPY

# Step 5

Press the (ENTER) key to display the copy-setting menu.

COPY COUNT 1

## Step 6

Use the and keys to select the desired number of copies, and then press the (ENTER) key to confirm. To cancel, press the (NEXT) or (PREV.) key.

## Step 7

The cutting/plotting operation starts for the number of copies selected.

# Step 8

To make further copies, replace the medium and repeat steps 2 to 6.

If the data to be copied does not fit within the cutting/plotting area, the following message is displayed in step 5.

CANNOT COPY


Use the **()**, **()**, and **()** (POSITION) keys to change the initial copying position or load a medium with an area of sufficient size to fit the copied data.

#### CHECKPOINT //

- If the initial cutting/plotting position was moved from the original origin, the new origin will also apply during the copying operation. To prevent wasteful use of the medium, the initial cutting/plotting position for the data should be as close as possible to the origin.
- If the cutting plotter receives another set of data during the copying operation, the operation will not be properly completed because the initial data is cleared during the operation. Do not send new data to the cutting plotter while copying is in progress.
- If new data is sent to the cutting plotter more than 10 seconds after the initial cutting data is sent, the original data will be cleared from the internal memory.
- Copying will not be possible if data exceeding 2 Mbytes is sent to the cutting plotter, as the data will cause the buffer memory to overflow.


#### 4.14 Sorting Settings

This function sorts and cuts or plots the cutting/plotting data stored in the buffer memory to minimize the amount of medium feed required. This is useful for data requiring a large number of movements on the drawing with the pen raised. If the data received has been sorted using the application software, sorting the data using the cutting plotter may require additional time. Turning this function off may speed up the process.




#### 4.15 Interface Settings

The interface conditions must be set if the RS-232C serial interface is used, to ensure that the data-transfer rate (baud rate), data length, and parity settings for the cutting plotter match those set in the application software or computer operating system. This section describes the interface conditions for the cutting plotter. For details on how to set the conditions for your application or computer operation system, refer to the manual provided with the application or operating system.



#### 4.16 Setting the Format of Data to be Received

Before data is sent from the computer, the format (command mode) of data sent by the application software must be checked. The cutting plotter accepts two data formats (command modes): GP-GL (Graphtec) and HP-GL commands. Set the command mode to suit the application used.



#### **■**Setting the Command Mode

## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

## Step 2

Press the (NEXT) or (PREV.) key until the following menu appears.

COMMAND

# Step 3

Press the (ENTER) key to display the command-setting menu.

COMMAND GP-GL

## Step 4

Press the or key to select "GP-GL" or "HP-GL," and then press the ENTER) key to confirm. To cancel the selection, press the (NEXT) or (PREV.) key.

## Step 5

If "GP-GL" is selected, set the STEP SIZE. If "HP-GL" is selected, set the ORI-GIN POINT. If a command different from that set previously is selected, the PAUSE mode is automatically canceled after STEP SIZE (GP-GL) or ORIGIN POINT (HP-GL) is set.

#### **■**Setting the STEP SIZE

If the GP-GL command mode is set, the minimum unit of distance that the pen can travel can be changed to one of four settings: 0.01 mm, 0.025 mm, 0.05 mm, or 0.1 mm. The default setting is 0.1 mm, so change this setting if your application specifies a different step size.

# Step 1

Set the command setting to "GP-GL."

COMMAND GP-GL

## Step 2

Press the (ENTER) key to display the step-size setting menu.

STEP SIZE 0.100mm

## Step 3

Use the and keys to select "0.100 mm," "0.050 mm," "0.025 mm," or "0.010 mm," and then press the (ENTER) key to confirm. To cancel the selection, press the (NEXT) or (PREV.) key.

## Step 4

Press the (PAUSE) key to cancel PAUSE mode.

#### **■** Setting the ORIGIN POINT

If the HP-GL command mode is set, the origin point can be set to the lower left or center. The default setting is the lower left, so change this setting if your application specifies a different origin position.

## Step 1

Set the command setting to "HP-GL."

COMMAND HP-GL

## Step 2

Press the (ENTER) key to display the origin-point setting.

ORIGIN PT L.L.

## Step 3

Press the or key to select "L.L. (LOWER LEFT)" or "CENTER," and then press the (ENTER) key to confirm. To cancel the selection, press the (ENTER) (NEXT) or (ENTER) (PREV.) key.

## Step 4

Press the (PAUSE) key to cancel PAUSE mode.

#### 4.17 Blade Wear Detection (When Blade Wear Setup is On)

This function calculates the total cutting distance of the cutter blade to indicate when it requires replacement. This should be used purely as a guide, as the actual cutter-blade wear will vary depending on the material cut and the cutting conditions (e.g., force) used.

The pen setting areas are grouped together, and the total distances are calculated for each group. Eight groups can be managed, and they initially correspond to the pen setting areas, so that group 1 corresponds to setting area 1, group 2 corresponds to setting area 2, and so on. If two or more setting areas are combined in a single group, the total calculated distance for that group will be the sum of the individual area values.

It is also possible to include weighting factors for each setting area to correspond to the different wear rates for different materials and cutting conditions. For example, if setting areas 1, 2, and 3 are combined into one group with respective total distances of A, B, and C, and the respective factors are 0.7, 1.2, and 1.0, the total distance for this group will be  $A \times 0.7 + B \times 1.2 + C \times 1.0$ .

Wear detection can be switched on or off using the special function settings (see "Enabling/Disabling Wear Detection" on page 5-3). When disabled, it is not displayed on the PAUSE menu.

If the power is turned off while cutting is in progress, the cutting distance for that operation is not included in wear-detection calculations.

#### **■** Checking the Wear Rate

## Step 1

Check to confirm that the cutting plotter is in READY mode (displaying the current pen settings).

1 PEN 23 30 2

## Step 2

Press the (NEXT) key to display the wear-rate menu for the group to which the above setting area belongs.

BLADE WEAR 60%

The wear rate is shown as 0% for a new pen, and 100% when the total distance exceeds the maximum distance for the cutter blade. Press the ((PREV.) key to return to READY mode.

## Step 3


The following message is displayed in READY mode if the wear rate exceeds 100% for the group to which the current setting area belongs.

EXCEEDS 100%

This indication should be used as a guide for cutter-blade replacement.

This display reverts to the normal READY-mode display when the (PREV.) key is pressed, but it will reappear when the power is turned on again or if a setting area is selected again for a group with a wear rate exceeding 100%.

Always zero the total distance display after replacing a cutter blade (see "Clearing the Total Distance (Wear Rate)"). The display above will disappear, and the distance calculation will restart from zero.



#### **■**Setting Wear-Rate Groups

This registers setting areas in groups.

## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

# Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

BLADE WEAR SETUP

# Step 3

Press the (ENTER) key to display the wear-rate setting submenu.

SET BLADE GROUP

## Step 4

Press the **(ENTER)** key to display the wear-rate group setting.

GROUP 1 12 45

## Step 5

The number on the left is the group number, and the numbers to the right of this indicate the setting areas belonging to it, separated by spaces. The display above indicates setting areas 1, 2, 4, and 5, belonging to group 1.

Use the and keys to move the cursor to the group number or setting-area number to be set. Pressing the or key at the group-number position increases or decreases the number, and pressing the or key at the setting-area number position displays or doesn't display the number. Select the required group number, display the setting-area numbers to be registered, and then press the (ENTER) key to confirm.

Each setting area can only be registered in one group. To register a setting area in another group, it must first be removed from the group in which it is registered. Initially, setting area 1 is set to group 1, setting area 2 to group 2, and so on, so setting areas must be removed from one group before being registered in another.

To cancel, press the (MEXT) or (MI) (PREV.) key.

#### **■** Setting Wear-Rate Factors

This sets factors corresponding to the differences in wear rates due to different materials and cutting conditions.

#### Step 1

Press the (PAUSE) key to switch to PAUSE mode.

## Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

BLADE WEAR SETUP

## Step 3

Press the (ENTER) key to display the wear-rate setting submenu, and then press the (NEXT) or (PREV.) key until the following menu is displayed.

FACTOR

## Step 4

Press the (ENTER) key to display the wear-rate factor setting.

COND 1 1.00

## Step 5

Use the and keys to increase or decrease the setting-area number, and use the and keys to increase or decrease the factor value. The factor can be set to between 0.10 and 1.00 in 0.10 intervals, and between 1.00 and 2.50 in 0.25 intervals. Once the wear-rate factor is set, press the (ENTER) key to confirm. To cancel, press the (NEXT) or (PREV.) key.

## Step 6

Press the (PAUSE) key to cancel PAUSE mode.

#### ■ Clearing the Total Distance (Wear Rate)

Always zero the total-distance display when a cutter blade has been replaced. This starts the total-distance calculation from zero.

## Step 1

Press the (PAUSE) key to switch to PAUSE mode.

## Step 2

Press the (NEXT) or (PREV.) key until the following menu is displayed.

BLADE WEAR SETUP

## Step 3

Press the (ENTER) key to display the wear-rate setting submenu, and then press the (INEXT) or (IPREV.) key until the following menu is displayed.

CLEAR GROUP

## Step 4

Press the (ENTER) key to display the wear-rate clear menu.

CLEAR GROUP1<YES>

# Step 5

The number to right of "CLEAR GROUP" is the group number. Use the 
and keys to increase or decrease the group number, and press the or key to select "YES" or "NO." Select "YES" for the group number to be cleared, and press the (ENTER) key to clear the total distance. To cancel, press the (NEXT) or (NEXT) or (PREV.) key.

## Step 6

Press the (PAUSE) key to cancel PAUSE mode.


#### 4.18 Raising and Lowering the Pen

This function raises and lowers the pen.



#### 4.19 TEST Mode

The cutting plotter has four test modes: "Condition print (COND. PAT.)" for the printing of setting details, "Self-test" for checking accuracy, "Dump mode" for checking data transfers from the computer, and "Cutting demo (CUT. DEMO)" for the cutting of a demo pattern. These should be used to check the various settings and to check for problems.



#### **■** Self-Test-Pattern Printing

This function prints out a self-test pattern to check the accuracy of the cutting plotter.

## Step 1

Mount a plotting pen in the pen carriage, and set the conditions to suit the pen used (e.g., force, pen speed settings).

## Step 2

Load an A3-size or larger medium.

# Step 3

Press the **(PAUSE)** key to switch to PAUSE mode.

## Step 4

Press the (NEXT) or (PREV.) key until the following menu is displayed.

TEST MODE

## Step 5

Press the (ENTER) key to display the test-mode submenu, and press the (NEXT) or (PREV.) key until the following menu is displayed.

SELF TEST

## Step 6

Press the (ENTER) key to start printing the self-test pattern.

# Step 7

When the self-test pattern has been printed, turn on the power again.

**CAUTION** The pen carriage begins moving as soon as this function is set. Keep your hands and other objects away from the cutting plotter's moving parts.

#### **■** Dump Mode

This function checks whether data is sent correctly from the computer. If the output data does not match the program after the dump list has been output, check the transfer conditions and connections.

## Step 1

Mount a plotting pen in the pen carriage, and set the conditions to suit the pen used (e.g., force, pen speed settings).

## Step 2

Load an A4-size or larger medium.

## Step 3

Press the (PAUSE) key to switch to PAUSE mode.

## Step 4

Press the (NEXT) or (PREV.) key until the following menu is displayed.

TEST MODE

## Step 5

Press the (ENTER) key to display the test-mode submenu, and press the (NEXT) or (PREV.) key until the following menu is displayed.

D U M P

## Step 6

Press the **(ENTER)** key to switch to dump mode.

CHAR DUMP MODE

## Step 7

When data is sent to the cutting plotter in this mode, a dump list is printed out. To exit the dump mode, turn on the power again.

#### CHECKPOINT

The dump list is printed out as ASCII character codes. Characters without codes will be printed as small 2-digit figures. Output data for READ-type commands will be output as dummy data, except for cutting-plotter status output.

**A** CAUTION

The pen carriage begins moving as soon as this function is set. Keep your hands and other objects away from the cutting plotter's moving parts.

#### ■ Cutting Demo

This function cuts a cutting-demo pattern.

## Step 1

Mount a plotting pen in the pen carriage, and set the conditions to suit the pen used (e.g., force, pen speed settings).

## Step 2

Load a film for cutting.

## Step 3

Press the (PAUSE) key to switch to PAUSE mode.

# Step 4

Press the (NEXT) or (PREV.) key until the following menu is displayed.

TEST MODE

# Step 5

Press the (ENTER) key to display the test-mode submenu, and press the (NEXT) or (PREV.) key until the following menu is displayed.

CUT DEMO

# Step 6


Press the (ENTER) key to start cutting the demo pattern.

**A**CAUTION

The pen carriage begins moving as soon as this function is set. Keep your hands and other objects away from the cutting plotter's moving parts.


#### 4.20 Setting the PEN UP SPEED

This function sets the travel speed of the pen when it is raised. It can be specified independently of the cutting SPEED function. When the PEN UP SPEED is high, the pen travels faster when it is raised, thereby reducing the overall cutting time. Your cutting plotter comes with its PEN UP SPEED set to AUTO, which selects the same speed as the cutting SPEED function (pen lowered). Note that if long-axis cutting of a medium is performed with a high PEN UP SPEED setting, the medium is susceptible to jamming.




#### 4.21 Setting the OFFSET FORCE (Initial Cutting Force)

This function specifies the cutting force to be applied during initial blade control for checking the cutter-blade direction at the start of operation. This is used to control the rotation of the cutter-blade tip during initial blade control when thick media is cut, and is therefore not necessary to specify for media of regular thickness. The initial setting is "4." Increasing this setting increases the cutting force.




#### 4.22 Setting the OFFSET ANGLE

This function sets the reference value used to adjust the cutter-blade offset angle to correspond to the displacement of the traveling angle as defined by the coordinate movement data received. The cutter blade is controlled above the angle specified. Setting a high value will reduce the total cutting time, but the corners of drawings cut will become rounded and may not be cut precisely. The initial setting is "30."




#### 4.23 Setting the STEP PASS

Reducing this setting increases image quality by enabling smooth cutter-blade tip control when arcs are cut. The STEP PASS setting specified is used as the unit for blade tip control, with blade tip control omitted for any data below the STEP PASS setting. If the STEP PASS setting is too high, the image cut may not be faithfully reproduced. Normally, the STEP PASS setting should be set to "1."




#### 4.24 Setting the Initial Down Force

The initial down-force setting is useful when TANGENTIAL mode is selected (for the cutting of thick media). With thick film, additional time is required for the cutter blade to penetrate the film fully, even when the necessary cutting force is applied. The cutting operation starts before the cutter blade has fully penetrated the film, causing uncut sections to be left. When the initial down force is specified, this force is used as the cutting force immediately after lowering of the pen when TANGENTIAL mode is selected, enabling the cutter blade to penetrate the medium rapidly. (If the cutting force is 25 and the initial down force is 4, for example, the cutting force applied immediately after lowering of the pen will be 29.) Set the initial down force to suit the type of film used by performing test cuts.



#### 4.25 Setting the LENGTH UNIT

This function specifies the units for coordinates displayed in millimeters or inches.



5.1	Description of Special Functions A	5-2
5.2	Setting Special Functions A	5-4
5.3	Description of Special Functions B	5-4
5.4	Setting Special Functions B	5-5

#### 5.1 Description of Special Functions A

The cutting plotter is provided with the special functions described below. These functions are specified only in special situations, and are not normally used.

#### ■ Enabling/Disabling the ":" and ";" Commands (when the COMMAND setting is GP-GL)

This function enables or disables the ":" and ";" commands when the COMMAND setting is GP-GL. If the first part of the data is lost, these commands may be having an adverse effect. In this case, set this function to DISABLE (the default setting is ENABLE).

# ■ Moving the Pen While Raised or Lowered in Response to the "W" Command (when the COMMAND setting is GP-GL)

This function selects whether, upon receipt of the "W" command for the drawing of arcs, the cutting plotter moves the pen to the specified starting position, raised or in the pen status (raised or lowered) that was in effect immediately prior to receipt of the "W" command.

When PEN DOWN is selected, the pen is moved to the starting position for the drawing of arcs in the pen status (raised or lowered) that was in effect immediately prior to receipt of the "W" command.

When PEN UP is selected, the pen is moved to the starting position for the drawing of arcs in the raised status. This setting is only effective if a cutter blade has been selected in the cutter-pen settings. (The default setting is PEN UP.)

#### ■ Model ID Response (when the COMMAND setting is HP-GL)

This function sets the response to the "OI" command when the COMMAND setting is HP-GL.

When 7550 is set, the "OI" command response is 7550.

When 7586 is set, the "OI" command response is 7586.

(The default setting is 7550.)

#### **■ SETTING PRIORITY**

This function sets whether the cutting plotter places priority on the cutting conditions specified through command input from the computer or through manual settings (on the cutting-plotter control panel).

When MANUAL is selected, cutting is performed using the cutting conditions set at the control panel, and cutting conditions sent from the computer are ignored.

When PROGRAM is selected, cutting is performed using the cutting conditions specified in a received cutting-condition command. If no commands are received, cutting is performed using the cutting conditions set at the control panel.

(The default setting is MANUAL.)

#### ■ Blade-Tip Initial Position Setting

The cutter blade is placed on the medium to orient it after the power is turned on or the cutter-pen conditions are set. This is referred to as "initializing" the cutter blade.

This function sets the "Blade-Tip Initial Position" for this operation.

When 2 mm BELOW is selected, initial blade control is performed at a position 2 mm below the cutting start position.

When OUTSIDE is selected, initial blade control is performed outside of the effective cutting/plotting area. (The default setting is 2 mm BELOW.)

#### **■** Enabling/Disabling PEN UP MOVE

This function sets whether the pen will travel to each point specified or only from the initially specified point to the last specified point when consecutive commands are received specifying pen movement while it is raised.

When ON is selected, the pen travels consecutively to each coordinate specified by the data received. When OFF is selected, the pen travels directly from the initially specified point to the last specified point. (The default setting is OFF.)

#### **■** Enabling/Disabling the Media Sensors

This function sets the media sensors that detect the size of the medium in the feed direction.

When ON is selected, the feed-direction media sensors are enabled.

When OFF is selected, the feed-direction media sensors are disabled.

(The default setting is ON.)

#### **■** Enabling/Disabling the Home Sensors

This function sets the home sensors that detect the width of the medium.

When ON is selected, the home sensors are enabled.

When OFF is selected, the home sensors are disabled.

(The default setting is ON.)

#### ■ Setting the PARALLEL I/F Mode

Parallel (Centronics-compatible) interfaces have various timing methods for their signal lines. If the signal timings do not match, data cannot be received accurately via the Centronics-compatible parallel interface. This function allows the timing of the Centronics-compatible parallel interface to be changed by selecting one of four different modes (1 through 4).

(The default setting is 1.)

#### ■ Circle-Command Resolution Setting (when the COMMAND setting is HP-GL)

This function sets whether the resolution is automatically set or fixed at a constant 5 degrees when a cutting-plotter circle command is output while the COMMAND setting is HP-GL. (The default setting is Auto.)

#### **■** Enabling/Disabling Blade Wear Detection

When ON is selected, the blade wear-detection setting is enabled and the blade wear-detection setting menu is displayed in the PAUSE menu.

When OFF is selected, the blade wear-detection setting is disabled, and the blade wear-detection setting menu is removed from the PAUSE menu and is not displayed. For details on wear detection, refer to "4.17 Cutter-Blade Wear Detection."

(The default setting is OFF.)





CAUTION If the media or home sensors have been disabled (set to OFF), be sure to specify the cutting/plotting area (see "Setting the Cutting/Plotting Area"). If the cutting/plotting area is not specified, the cutting mat may be damaged.

#### 5.2 Setting Special Functions A

## Step 1

Turn on the cutting plotter while holding down the **key**. The menus for setting the special functions are displayed.





Step 2

Scroll up or down to select the required menu using the (NEXT) or (PREV.) keys.

# Step 3

Select the setting details using the \( \to \) and \( \to \) keys, and press the \( \to \) (ENTER) key to register the setting. To cancel, press the \( \to \) (NEXT) or \( \to \) (PREV.) key. The next menu is displayed.

# Step 4

Once all the settings have been made, turn off the cutting plotter.

## 5.3 Description of Special Functions B

These functions are specified only in the special situations described below, and are not normally used.

#### ■ Display Language Setting (MENU LANGUAGE SELECTION)

This function sets the language used on the display. One of six languages can be selected: English, French, German, Italian, Spanish, or Japanese.

## 5.4 Setting Special Functions B

# Step 1

Turn the cutting plotter on while holding down the (ENTER) and (ORIGIN) key simultaneously. The special functions B setting menu is displayed.

DISPLAY ENGLISH

# Step 2

Use the  $\bigcirc$  and  $\bigcirc$  keys to select the desired display language, and then press the  $\bigcirc$  (ENTER) key to confirm. To cancel, press the  $\bigcirc$  (NEXT) or  $\bigcirc$  (PREV.) key.

# Step 3

Once all the settings have been made, turn off the cutting plotter.

6.1	The Cutting Plotter Does Not Operate When Turned	l On
		6-2
6.2	The Cutting Plotter Does Not Operate Correctly	6-2
6.3	The Cutting Results Are Unsatisfactory	6-3
6.4	An Error Message Was Displayed	6-4

# 6.1 The Cutting Plotter Does Not Operate When Turned On

Symptom	Cause	Solution
The STATUS lamp on the control panel does not light up.	Power is not being fed to the cutting plotter.	Check to confirm that the power cord is securely connected to the cutting-plotter AC line inlet and the electrical outlet.
The STATUS lamp on the control panel lights up, but nothing appears on the display panel.	The cutting plotter is defective.	Contact your sales representative or nearest Graphtec dealer.

# 6.2 The Cutting Plotter Does Not Operate Correctly

Symptom	Cause	Solution
OFFSCALE is displayed when data is received.	The data received lies outside the cutting/plotting area set.	Set the cutting/plotting area. Check the page-length setting.
Some areas cannot be cut.	The data received is larger than the cutting/plotting area set.	Replace with a larger-size medium. Reduce the data size.
Cannot maintain the cut- ting conditions	The cutter-pen condition-setting priority is set to PROGRAM.	Set the condition setting priority to MAN-UAL.
Cannot change the cutting conditions	ENTER was not pressed after the settings were changed.	Check the operation and reset the cutter-pen conditions.
"LOAD MEDIA" is displayed even when the	The medium is semi-transparent and is not detected by the media sensors.	Set the media-sensor setting to DIS-ABLE, and set the cutting/plotting area.
medium has been loaded.	The medium is not detected by the media sensors due to strong reflected light.	Change the lighting direction and avoid direct sunlight.
	The medium is not loaded so that it passes the media sensors.	Load so that the medium passes over the media sensors.
	The right-hand pinch roller is not positioned over the right-hand long grit roller.	Position the right-hand pinch roller over the right-hand long grit roller.
The medium is skewed.	The left-hand pinch roller is not positioned over the left-hand grit roller.	Position the left-hand pinch roller over the left-hand grit roller.
	The medium was loaded at an angle.	Reload the medium.
	The length of the medium to be cut was not drawn out first when the medium was loaded.	Draw out the required length of roll medium to be used.
The medium is suddenly fed forward.	The selections for medium loading are incorrect.	Check the medium selection (ROLL1 PRESS ENTR, ROLL2 PRESS ENTR, SHEET PRESS ENTR).
Abnormal noise is generated by the cutter during cutting.	The cutter plunger tip is in contact with the medium.	Adjust the cutter-blade extension. Reduce the cutting force.

# 6.3 The Cutting Results Are Unsatisfactory

Symptom	Cause	Solution	
The cut corners are too rounded or too pointed.	The cutter offset does not match the blade type used.	Adjust the cutter offset value. Corners are rounded: Increase the value. Corners are pointed: Reduce the value.	
The medium curls up at the	The blade offset angle is too small.	Increase the offset angle.	
corners.	The blade is extended too far.	Adjust the blade extension length.	
	The cutter offset does not match the blade type used.	Adjust the offset.	
	The cutting speed is too high.	Reduce the cutting speed.	
	The blade is dull.	Replace the cutter blade.	
Only the initial section cut is satisfactory.	The cutter blade is not rotating smoothly in the holder.	Clean inside the holder.	
	The offset force is insufficient.	Increase the offset force.	
	The CB09UA spring is missing.	Replace the blade with a spring attached.	
The cutter blade does not	The blade is extended too far.	Adjust the blade extension length.	
completely cut lines that should be solid (blade skips). Solid lines are not cut at a constant depth (mild skipping).	The cutting speed is too high.	Reduce the cutting speed.	
Curved lines have coarse resolution.	The cutting data is too coarse.	Correct so that the application data is output with greater detail.	
	The blade offset angle is too small.	Increase the offset angle.	
Characters or complex figures are deformed.	The step-pass setting is too large.	Reduce the step-pass setting.	
The cutting start and end points for figures do not	The data is not connected.	Check by plotting using a pen, and correct the data.	
match.	The offset force is too low.	Increase the offset force.	
	The film is too flimsy.	Use a stiffer film.	
	The cutter blade is not rotating smoothly in the holder.	Clean inside the holder.	
Cannot cut to the specified size	The step size for the software and the cutting plotter do not match.	Adjust the step-size settings so that they match.	
	Scaling has been specified in the software.	Check the scaling.	
The length cut differs from that specified.	The medium is slipping.	Reduce the cutting speed. Reduce the pen-up speed.	
	The distance correction is not correct.	Adjust the distance correction.	
The medium is discolored where the blade cut.	The cutter plunger tip is in contact with the medium.	Adjust the blade extension length. Reduce the cutting force.	
The cutter blade cuts into the	The blade is extended too far.	Adjust the blade extension length.	
backing sheet.	The cutting force is too high.	Reduce the cutting force.	

Symptom	Cause	Solution	
The medium is cut, but it is difficult to weed afterward.	The retack sheet is not sufficiently adhesive.	Use a retack sheet with greater adhesion.	
The cut medium cannot be picked up using a retack sheet.	The medium becomes entangled after cutting.	Adjust the blade extension length. Reduce the cutting force.	
	Weeding of the cut medium was left too long.	Weed the cut medium promptly.	
Characters and lines are deformed when plotted using the pen.	A blade has been selected in the cutter-pen settings.	Select PEN.	

## 6.4 An Error Message Was Displayed

Symptom	Cause	Solution	
CURRENT LIMIT or POSI- TION ERROR is displayed.	The cutting conditions are not suitable for the medium being cut.  Reduce the cutting Reduce the cutting		
The POWER lamp flickers.	Excessive load is causing the current to the motor to exceed the rated value.	Remove the obstruction and turn the cutting plotter back	
	The pen carriage movement is being obstructed.	on.	
	The pen carriage was subjected to external pressure during cutting.		
	Scraps of the medium in the moving parts are impeding operation.		
	If this problem occurs frequently, contact your sales representative or nearest Graphtec dealer.		
SPEED ERROR is displayed. The POWER lamp flickers.	The pen carriage was subjected to external pressure after the power was turned on.  Turn the cutting plant and then back on		
	The internal speed control is faulty.		
	If this problem occurs frequently, contact your sale Graphtec dealer.	es representative or nearest	

If any of the following command error messages appear, they are nearly always caused by one of the following two reasons:

- The software or host-computer settings have been changed.
- The cutting-plotter interface settings have been changed.

#### **Solutions**

- Configure the settings in the software menu so that the menu can control the cutting plotter.
- · Set the host-computer interface conditions correctly.
- Set the cutting-plotter interface conditions correctly.

## Error messages in GP-GL command mode

Error message	Cause	Solution
GP-GL ERROR 1	An unrecognizable command was received.	
	Noise was received when the computer was turned on.	Press the ENTER key to cancel the error.
	The software command settings for controlling the cutting plotter have been changed.	Set the software command settings for controlling the cutting plotter.
	The data-transmission settings have been changed in the interface settings.	Set the correct data-transmission conditions.
GP-GL ERROR 2	The command terminator is incorrect.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
	The data-transmission settings have been changed in the interface settings.	Set the correct data-transmission conditions.
GP-GL ERROR 3	The command delimiter is incorrect.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
	The data-transmission settings have been changed in the interface settings.	Set the correct data-transmission conditions.
GP-GL ERROR 4	The command parameter exceeds the permissible range.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
	The data-transmission settings have been changed in the interface settings.	Set the correct data-transmission conditions.
GP-GL ERROR 5	An error occurred in the reception of data within the interface.	
	The software command settings for controlling the cutting plotter have been changed.	Set the software command settings for controlling the cutting plotter.
	The data-transmission settings have been changed in the interface settings.	Set the correct data-transmission conditions.

## Error messages in HP-GL command mode

Error message	Cause	Solution
HP-GL ERROR 1	An unrecognizable command was received.	
	Noise was received when the computer was turned on.	Press the ENTER key to cancel the error.
	The software command settings for controlling the cutting plotter have been changed.	Set the software command settings for controlling the cutting plotter.
	The data-transmission settings have been changed in the interface settings.	Set the correct data-transmission conditions.
HP-GL ERROR 2	The command was executed with the wrong parameters.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
	The data-transmission settings have been changed in the interface settings.	Set the correct data-transmission conditions.
HP-GL ERROR 3	The command parameter is incorrect.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
HP-GL ERROR 5	An unrecognizable character set was specified.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
HP-GL ERROR 6	The command coordinates specified are outside the cutting/plotting area.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
HP-GL ERROR 7	The buffer overflowed when the downloadable-character buffer or polygon buffer was used.	
	The software settings for the output device have been changed.	Set the software command settings for controlling the cutting plotter.
HP-GL ERROR 10	Another output command was executed while a command was already being executed.	
	An invalid command was received following an ESC code.	Set the software command settings for controlling the cutting plotter.
	An invalid byte was received within a device control command.	
	A parameter outside the permissible range was specified in an I/O command.	
	There were too many parameters in an I/O command.	
	A framing error, parity error, or overrun error occurred.	Set the correct data-transmission
	The interface buffer overflowed.	conditions.

# APPENDIX

Appendix A	Main Specifications	. A-2
Appendix B	Options and Supplies	. <b>A</b> -3
Appendix C	External Dimensions	. A-4
Appendix D	Menu Tree	<b>A</b> -6

# Appendix A Main Specifications

Item	CE3000-40	CE3000-60	CE3000-120
CPU	32-bit CPU		
Configuration	Grit rolling		
Drive system	Stepping Digital servo		
Maximum cutting area	375 mm x 50 m	603 mm x 50 m	1213 mm x 50 m
Range of guaranteed precision	356 mm x 2 m <sup>*1</sup>	584 mm x 5 m <sup>*1</sup>	1194 mm x 5 m <sup>*1</sup>
Compatible media widths	Minimum: 50 mm Maximum: 484 mm (19 inches)	Minimum: 50 mm Maximum: 712 mm (28 inches)	Minimum: 85 mm Maximum: 1346 mm (52 inches)
Maximum media thickness	10 mil		
Maximum cutting speed	40 cm/s (in all directions)	60 cm/s (in all directions)	100 cm/s (45° direction)
Maximum acceleration	5 m/s <sup>2</sup> (45° direction)	21.2 m/s <sup>2</sup> (45° direction)	14.1 m/s <sup>2</sup> (45° direction)
Specifiable cutting speeds	1–10, 15, 20, 25, 30, 35, 40 cm/s	1–10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60 cm/s	1–10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60, * cm/s
Cutting force	20 gf to 300 gf (31 levels)		20 gf to 450 gf (38 levels)
Minimum character size	Approximately 5 mm for alphanumeric characters (varies depending on the medium, font, etc.)		
Mechanical resolution	0.0125 mm 0.005 mm		
Programmable resolution	GP-GL: 0.1/0.05/0.025/0.01 mm; HP-GLM *2: 0.025 mm		
Repeatability precision	0.1 mm or less per 2 m <sup>*1</sup>		
No. of pens mountable	1 pen		
Compatible cutter type	Supersteel cutter blades		
Compatible pen type	Water-based fiber-tip pens		
Compatible cutting film	Marking film (PVC, fluorescent, or reflective film) up to 0.25 mm in thickness (excluding high-luminosity reflective film)		
Interfaces	RS-232C/Centronics/USB		
Buffer capacity	2 MB		
Command modes	GP-GL, HP-GL <sup>TM *2</sup> (selected on the control panel)		
Display panel	Liquid crystal display (16 c	characters x 1 row)	
Rated power supply	100 to 120 V AC, 200 to 240 V AC, 50/60 Hz		
Power consumption	70 VA 100 VA		
Operating environment	10°C to 35°C, 35% to 75% RH		
Conditions for guaranteed precision	16°C to 32°C, 35% to 70% RH		
External dimensions (W x D x H)	Approx. Approx. Approx. Approx. 1,487 x 656 x 1188 mm*3		
Weight	9.4 kg 11.2 kg 39.1 kg <sup>*3</sup>		39.1 kg <sup>*3</sup>

<sup>\*1:</sup> Varies depending on the type of Graphtec-authorized film and the cutting conditions \*2: HP-GL<sup>TM</sup> is a registered trademark of Hewlett-Packard Company. \*3: Including the stand

# Appendix B Options and Supplies

## **■** Options


Designation	Part No.	Description
Stand	ST0045	Stand for CE3000-60
Basket	PG0016	Basket for CE3000-60
	PG0007	Basket for CE3000-120
Loupe	PHP-61LOUPE	Loupe with 6x magnification


#### ■ Supplies


Designation	Part No.	Description
Cutter holder	PHP32-CB09N	1 holder for the 0.9-mm-diameter supersteel blade
	PHP32-CB15N	1 holder for the 1.5-mm-diameter supersteel blade
Cutter blade	CB09UA-5	Set of 5 0.9-mm-diameter supersteel blades
	CB15U-5	Set of 5 1.5-mm-diameter supersteel blades
	CB15UB-5	Set of 5 1.5-mm-diameter supersteel blades for cutting detailed characters
Water-based fiber-tip pen	KF550-F8	1 pen each in red, black, violet, brown, blue, green, orange, and pink
	KF550-S1	2 black pens and 1 pen each in red, blue, and green
	KF551-RD	5 red pens
	KF552-BK	5 black pens
	KF555-BL	5 blue pens
	KF556-GR	5 green pens
	* Other sets of water-based fiber-tip pens are also available in single colors (violet, brown, orange, or pink) or intermediate shades.	

# **Appendix C** External Dimensions

#### **■** CE3000-40










Units: mm Dimensional accuracy: ±5 mm

#### **■ CE3000-60**









Units: mm Dimensional accuracy: ±5 mm

#### ■ CE3000-60 (When mounted on optional stand)




 $\begin{array}{c} \text{Units: mm} \\ \text{Dimensional accuracy: } \pm 5 \text{ mm} \end{array}$ 

#### **■** CE3000-120



Units: mm Dimensional accuracy: ±5 mm

## Appendix D Menu Tree



# **INDEX**

A	Dump mode4-40
AC power cord 1-2	
AC power inlet1-3, 1-5	E
Accessories1-2	Enabling/disabling blade wear detection5-3
Adjusting the blade length2-13	Enabling/disabling PEN UP MOVE5-3
Adjusting the registration-mark reading	Enabling/disabling the ":" and ";"
sensor (1) 4-16	commands5-2
Adjusting the registration-mark reading	Enabling/disabling the home sensors5-3
sensor (2) 4-17	Enabling/disabling the media sensors5-3
Aligning the coordinate axes 4-20	ENTER1-6
Aligning the push rollers2-9	Error messages in GP-GL command mode6-5
An error message was displayed 6-4	Error messages in HP-GL command mode6-6
Assembling the stand1-7	Expanding the cutting/plotting area4-26
Attaching the basket 1-10	External dimensions A-4
AUTO PRE-FEED 4-4	
Auto-registration-mark-reading settings 4-6	G
	GP-GL ERROR6-5
В	Grit roller 1-3, 1-4
Basket attachment instructions 1-10	<del>-</del> ,
Blade-tip initial position setting 5-2	Н
, ,	HP-GL ERROR6-6
C	TII -GE ETITOTI0-0
Checking the wear rate 4-34	1
Circle-command resolution setting	l disease le man
Clearing the buffer memory	Indicator lamp1-6
Clearing the total distance (wear rate) 4-36	Interface settings4-31
COND 1-6	
Condition-list printing4-39	L
Connecting to your computer2-2	Loading the medium2-4
Control panel	Loading the roll medium2-6
Cutter blade (CB09UA) 1-2	Loading the Roll Medium on the Roll-Medium
Cutter plunger 1-2	Trays (CE3000-40/60)2-4
Cutter-pen construction	
Cutting demo	M
Cutting mat	Main specifications A-2
Cutting/plotting using the buffer memory (COPY	Media cutter1-2
function)	Media set lever 1-3, 1-4
14 1011011)	Medium and registration-mark position4-8
D	Menu treeA-6
	Model ID response5-2
Description of special functions	Moving the pen3-9
Display language setting	Moving the pen carriage in +100 mm
Displaying the effective cutting area	steps3-11
Distance adjustment	
Drawing origin point 4-9	

Moving the pen while raised or lowered in	S	
response to the "W" command (when the	Self-test-pattern printing	4-40
COMMAND setting is GP-GL)5-2	Serial (RS-232C) interface connector 1	
	Setting FORCE	3-7
N	Setting OFFSET	
NEXT 1-6	SETTING PRIORITY	
	Setting QUALITY	
0	Setting special functions	
Optimal cutting conditions for each	Setting SPEED	
media type	Setting the command mode 3-:	
Options	Setting the cutter-pen	
Options and suppliesA-3	Setting the cutting/plotting area	
ORIGIN 1-6	Setting the FEED function	4-3
Origin point	Setting the format of data to be	
G.1.g.1. po	received 3-	2, 4-32
P	Setting the initial cutting position	
-	(origin point)	3-9
Parallel (Centronics) interface connector	Setting the interface conditions	3-4
Parts names and functions 1-3	Setting the LENGTH UNIT	4-48
PAUSE1-6	Setting the OFFSET ANGLE	4-45
PAUSE menu list	Setting the OFFSET FORCE	
Pen carriage1-3, 1-4	(initial cutting force)	4-44
Pen holder	Setting the ORIGIN POINT3-	3, 4-33
POSITION	Setting the PAGE LENGTH	4-24
Power switch 1-3	Setting the PARALLEL I/F Mode	5-3
PREV 1-6	Setting the PEN UP SPEED	4-43
Push rollers	Setting the registration-mark distance	
1 0, 1 1	adjustment	4-14
Q	Setting the registration-mark pattern	4-12
Quick start manual 1-2	Setting the STEP PASS	4-46
Quick Start Irianual1-2	Setting the STEP SIZE 3-	3, 4-32
В	Setting TOOL (cutter blade or pen)	3-6
R	Sorting	4-30
Raising and lowering the pen4-38	Stand 1	
Reading range required for the detection of	Stand assembly instructions	1-7
registration marks	Stand construction	
Reference pen conditions for plotting pens 3-5	STATUS	
Registration-mark mode	Stock rollers1-5, 2	
Registration-mark pattern	Stop function	
Registration-mark size	Stoppers	1-5
Replacing the cutter blade	Storing and selecting cutter-pen-condition	
Roll-medium trave 1-2	setting areas	
Roll-medium trays	Supplies	A-3
Roll-medium-tray guide rail	_	
Rotating the coordinate axes 4-27	Т	
	TANGENTIAL mode	4-5
	TEST	1-6

Test cutting	3-12
TEST mode	4-39
The cutting plotter does not operate	
correctly	6-2
The cutting plotter does not operate when	
turned On	6-2
The cutting results are unsatisfactory	6-3
The initial down force	4-47
Troubleshooting	6-1
Turn the blade-length adjustment	2-12
Turning on the power	2-3
Types and features of cutter blades	2-11
U	
USB interface connector1-	3, 1-4
User Guide CD-ROM	1-2
W	
Water-based fiber-tip pen	1-2
Wear detection	4-34
Wear-rate groups	. 4-35

The specifications, etc., in this manual are subject to change without notice.

CE3000-UM-151

February 27, 2003 1st edition-01

**GRAPHTEC CORPORATION**